## September 2016



1. INT	RO	DUCTION	7
1.1.	Abo	ut this document	. 7
1.2.	Proc	duct overview	. 7
2. QU	ICK	START	7
2.1.	Equi	ipment	. 7
2.2.	Data	alogger installation	. 8
2.2.2	1.	Initialize datalogger	. 8
2.2.2	2.	Sensor connection	10
2.2.3	3.	Datalogger mounting	10
2.3.	Data	alogger configuration	11
2.4.	Gate	eway installation	17
2.4.2	1.	Gateway overview	17
2.4.2	2.	Powering the Gateway	19
2.4.3	3.	Mounting of the enclosure	21
2.4.4	4. -	SIM Card	24
2.4.	э.	Ethernet connection	25
2.5.	Gate	eway configuration	25
2.5.2	1.	Connecting to the Gateway	25
2.5.2	2.	The Gateway's configuration and data access interface	26
2.6.	Data	a visualization and retrieval	39
2.7.	Mai	ntenance	44
2.7.2	1.	General Maintenance	44
2.7.2	2.	Periodical maintenance	44
2.7.3	3.	Return material authorization	45
3. LS-	-G6	DATALOGGERS	6
3.1.	LS-C	G6-VW	46
3.1.1	1.	Sensor connection	46
3.1.2	2.	Barometric measurements	47
3.1.3	3.	Battery lifespan	47
3.1.4	4.	Configuration	48
3.1.5	5.	Data storage	48
3.2.	LS-C	36-DIG	48
3.2.2	1.	Sensor Connection	48
3.2.2	2.	Battery lifespan	50
3.2.3	3.	Configuration	50
3.2.4	4.	Data storage	50
3.3.	LS-C	G6-ANALOG	51
3.3.2	1.	Sensor Connection	51
3.3.2	2.	Battery lifespan	52
3.3.3	3.	Configuration	53
3.3.4	4.	Data storage	53

4. WIRELESS RADIO	
<ul> <li>4.1. Maximum number of dataloggers connected in a network</li> <li>4.2. Radio configuration</li></ul>	
5 CONTACT WORI DSENSING	60
Anney 1: Details of mounting systems	F1
Mounting brackets	61
Strong magnets Pole mounting	
Annex 2: Android compatibility	66
Annex 3: LS-G6 water tightness	67
Annex 4: Recommended batteries	68
Annex 5: Communications security	69
Long range radio communication from dataloggers to gateway	
Security Encryption	69 69
Gateway user access	
Remote access	70 70
Annex 6: Connecting an external modem to LS-G6	72
Initial configuration of AirLink RV50 (via Ethernet cable) Final Step: Connecting the LS-G6 Gateway to AirLink RV50	72 75
Annex 7: Connecting a Wi-Fi module to LS-G6	76
<ul> <li>Interconnection between Wireless Bridge and Loadsensing Gateway</li> </ul>	/76
Annex 8: Troubleshooting reference table	79
Gateway Dataloggers	79 79
Annex 9: FAQ's	80
Annex 10: Modbus memory maps	82
General Section	

## FIGURES

Figure 1: View of the recommended positions to open the datalogger	9
Figure 2: Removal of the upper enclosure of the battery holder	9
Figure 3: Detail of power switch (SW A)	10
Figure 4: Detail of the grounding screw	11
Figure 5: a) Main screen of Android Configuration App and b) Node configuration screwhich has to be accessed for the configuration of the datalogger	en, 11
Figure 6: Network size configuration.	12
Figure 7: Sensor configuration options for LS-G6-VW-5 ch.	13
Figure 8: Sensor configuration options of LS-G6-DIG-2 ch.	13
Figure 9: Sensor configuration options of LS-G6-ANALOG-4ch	14
Figure 10: Data readings of active sensors.	15
Figure 11: Radio configuration screen	15
Figure 12: Radio signal coverage performed at the end of the datalogger setup (using Setup wizard).	the 17
Figure 13: LS-G6 Gateway, with all the parts indicated	18
Figure 14: LS-G6 Gateway opened.	19
Figure 15: Detail of the connections for the Power through PoE	19
Figure 16: a) Section of shielded Ethernet cable; b) Detail of the connection for the Pov through PoE using a shielded Ethernet cable	ver 20
Figure 17: Wiring of the cable at the RJ45 connector (following T-568A/B specification) be inserted in the PoE Injector.	to 20
Figure 18: DC terminal block	21
Figure 19: Gateway mounted on a pole	21
Figure 20: Gateway mounted on the wall.	22
Figure 21: Gateway mounted on a pole	22
Figure 22: Gateway's antenna mounting	23
Figure 23: Connection of the antenna cable to the connector	23
Figure 24: Fixing of the antenna cable	24
Figure 25: SIM card slot. Extraction button indicated	24
Figure 26: PoE. Left port (Data & Power Out) is for the power cable and right port (Data is for data transmission.	₃ ln) 25
Figure 27: Initial page of the gateway. This is the first page when entering the Web's Configuration Interface.	27
Figure 28: Summary of the datalogger status and the history of received / lost messag	es. 28
Figure 29: Gateway status page	31
Figure 30: View of the tool to create a self-configured csv file of the network data	32
Figure 31: View of the Internet configuration tab of the gateway. The present	
configuration is the one by default	33
Figure 32: Options for manual configuration	34
Figure 33: Settings for the configuration of the GPRS/3G connection	35

Figure 34: Remote Access tab, inside the gateway interface.	36
Figure 35: Radio configuration tab, inside the gateway interface	38
Figure 36: Delete all tab, inside the gateway interface	38
Figure 37: Reboot tab, inside the gateway interface	39
Figure 38: In the "Last readings" tab, a gear icon appears on the right, for editing the formula of the sensor	39
Figure 39: Menu to edit the formulae for transforming the raw data of the sensors into engineering units	40
Figure 40: Circled in red, the icon to display the charts of each of the sensors	41
Figure 41: Example of a chart of one datalogger	41
Figure 42: View of the screen where the .csv files of raw data and data transformed into engineering units (of the complete network) can be downloaded	41
Figure 43: View of the screen where the data of a specific datalogger can be downloade	ed. 42
Figure 44: View of the screen where the FTP can be configured	43
Figure 45: View of last messages received by the gateway, displayed in API format	44
Figure 46: Detail of a terminal block.	46
Figure 47: View of the inside of the digital datalogger connected to a RST inclinometer and b) Sisgeo inclinometer	49
Figure 48: View of the LS-G6-ANALOG datalogger internally where the four channels ca be identified.	in 51
Figure 49: View of the wiring of the different types of analogue sensors, indicated in the Android Configuration App.	e 52
Figure 50: Summarized scheme of data transmission over time in a LS-G6 network	54
Figure 51: View of the geographical display (in the software of the gateway) indicating t	he 58

## TABLES

Table 1: Connections of the terminal block	16
Table 2: Indicative lifespan for LS VW-datalogger 1 ch (using 1 C-size cell) and LS-VW-datalogger 5 ch. (using 4 C-size cells)	<del>1</del> 7
Table 3: Times of data storage (without overwriting) for LS VW-datalogger 1 ch and LSVW- datalogger 5 ch.	18
Table 4: Indicative lifespan for LS-DIG datalogger. Estimations using 4 c-size cells	50
Table 5: Indicative lifespan for LS-DIG datalogger. Estimations using 4 c-size cells	50
Table 6: Indicative storage capacity of the LS-DIG datalogger. Estimations using 5         sensors.	50
Table 7: Indicative lifespan for LS-ANALOG datalogger. Estimations using 4 c-size cells, considering SF9	52
Table 8: Indicative storage capacity of the LS-ANALOG datalogger. Estimations using 4 sensors.         Example 1	54
Table 9: Slot times table. Columns are the number of nodes; rows are sampling rate. Slot times are in seconds.	t 54

Table 10: Summary of radio specifications b	y mode 57
---	-----------

## 1. INTRODUCTION

## 1.1. About this document

This user guide explains the basic procedure for data acquisition with the Loadsensing LS-G6 family of dataloggers from Worldsensing Industrial (WSI). Further technical description is available in the datasheets.

The family of dataloggers LS-G6 from Worldsensing Industrial comprises 5 different dataloggers which may be used as standalone dataloggers (without remote communications) and radio dataloggers (with remote communications through a gateway). The available models are:

Dataloggers

- LS-G6-VW-1
- LS-G6-VW-1P
- LS-G6-VW-5
- LS-G6-DIG-2
- LS-G6-ANALOG-4

Gateway

LS-G6-GW<sup>1</sup>

#### 1.2. Product overview

Worldsensing's LS-G6 dataloggers are low power, easy to use and field-friendly, and are used for data acquisition from a great range of sensors in the market. Moreover, radio models can be used for long range communications, up to 15 km in open-field scenarios, and 4 km in urban scenarios.

LS-G6 dataloggers are battery powered, and easily configured through the Android Configuration App. The dataloggers and the gateway are robust (IP68 dataloggers, IP67 gateway) and don't need recasing.

LS-G6 dataloggers are used in a wide range of professional sectors, such as civil engineering, mining, environmental or industrial monitoring, among others.

## 2. QUICK START

## 2.1. Equipment

Worldsensing's LS-G6 system is shipped with the following accessories:

• LS datalogger accessories:

Included:

<sup>&</sup>lt;sup>1</sup> Gateways adjust to different geographic areas

- **RTC ½ AA-size bobbin cell battery**: Required to keep the time. If no RTC battery installed, the datalogger does not keep time.
- Antenna (only for radio models)

Not included:

- Micro USB OTG to USB 2.0
- External **mounting brackets** (set of 2) for wall mounting (see Annex 1 for details)
- Plate for pole mounting (see Annex 1 for details)
- **Strong magnets** for mounting in metallic structures (see Annex 1 for details)
- **C-size spiral cell batteries** (see Annex 4 for details): 1 to 4 batteries can be connected.

• Gateway accessories:

Included:

- Antenna
- Cable antenna
- PoE
- USB Local Administration Interface

Not included:

- Dataline surge protector
- Antenna surge protector

## 2.2. Datalogger installation

#### 2.2.1. Initialize datalogger

The datalogger is shipped closed and without batteries installed. In order to initialize it, the user should follow these steps:

a. Open the datalogger (using a 2.5 mm Allen wrench) following the recommended positions (Figure 1) in order to avoid damaging the lateral gore valve. The batteries are inserted onto the cover, so be careful not to snap the cable between the cover and the main board.



#### Figure 1: View of the recommended positions to open the datalogger.

b. Insert the RTC battery (small battery included). First remove the upper enclosure of the battery holder (Figure 2). Polarity is indicated inside the holder.



Figure 2: Removal of the upper enclosure of the battery holder.

The RTC battery keeps time in the datalogger whether or not C-type batteries are also inserted. UTC time is always used, however in the gateway or the Android configuration app, the data can be visualized in local time.

The single channel vibrating wire dataloggers (LS-G6-VW-1 and LS-G6-VW-1P) don't have an RTC battery to keep the time, therefore it is very important that the datalogger is powered with batteries and the time set during the installation. Otherwise the node will be in year 1970 and data will not appear in the gateway (a warning will appear in the log's tab).

c. Insert C-type batteries in the battery holders. 1 to 4 batteries can be connected. Polarity is indicated (see Annex 4 for further information on the batteries).

Note that there is reverse battery protection, but it is not safe to keep batteries reversed in the datalogger for a long time.

WARNING: RISK OF EXPLOSION IF THE BATTERIES ARE SUBSTITUTED WITH AN INCORRECT MODEL. DISPOSE OF BATTERIES ACCORDING TO THE INSTRUCTIONS. THIS EQUIPMENT IS MEANT TO BE INSTALLED IN RESTRICTED ACCESS AREAS.

 check that power switch (SW A, Figure 3) is in the correct position. USB: the datalogger is powered by the USB cable connected to any other Android device / BATT (default): the datalogger is powered by the batteries.

Note that some Android devices are not capable of powering the datalogger, especially when performing a reading. If reading fails, set the switch to BATT mode in order to power the datalogger with batteries.



Figure 3: Detail of power switch (SW A).

#### 2.2.2. Sensor connection

Sensors are connected to the datalogger at the terminal blocks. Each terminal block corresponds to one channel of the data logger. The terminal blocks accept wires that are prepared by stripping a short length of insulation from the end.

Each datalogger type has specific instructions for sensor wiring. The specifications for each model can be found in sections: 3.1. (vibrating wire dataloggers), 3.2. (digital dataloggers) and 3.3. (analogue dataloggers).

#### 2.2.3. Datalogger mounting

Dataloggers can be mounted (see Annex 1 for specific details):

- On the wall: mounting brackets can be supplied as additional accessories
- On a metallic structure: strong magnets can be supplied as additional accessories
- On a pole: plates for 35 and 50 mm pole diameters can be supplied as additional accessories for this mounting type
- Inside a manhole (with plastic or metallic cover): no special accessories are available for this mounting type. Even though the dataloggers are IP68 certified, we recommend installing them in holes with proper drainage so that they won't be permanently covered in water.

All LS-G6 dataloggers are protected against lightning, and there is an easy to use grounding screw (Figure 4), next to the cable glands, which may be connected to guarantee protection.



Figure 4: Detail of the grounding screw.

Note that in order to protect the datalogger from surges (especially on installations with long cable runs) the datalogger must be properly grounded via connection to the grounding screw.

## 2.3. Datalogger configuration

a)

Different configuration parameters are required for each type of datalogger (Vibrating Wire, Digital, Analogue). Complete configuration is done through the Android Configuration App (see Annex 2 for Android compatibility). When a new version of the app is available, a message appears automatically when connecting the datalogger by USB.

The configuration of the sensors and the radio is accessed by clicking the Setup wizard (in the tab menu "Node configuration", Figure 5). Inside the Node configuration menu, there are also other parameters that can be changed by the user, such as the Node ID or the date and time (especially important when accessing the Node for the first time, or after installing the RTC battery).



b)

Figure 5: a) Main screen of Android Configuration App and b) Node configuration screen, which has to be accessed for the configuration of the datalogger.

By selecting the Setup wizard, the step-by-step configuration of the sensors and the radio is started:

1) Network size. The size of the network (Figure 6) defines the slot time for each of the dataloggers to send data to the gateway, in order to avoid data collision (see section 4.1. of this user guide).

Network Size 21-100 nodes Standalone 1-20 nodes 21-100 nodes 101-200 nodes 201-1000 nodes 1001 2000 andes	<b>≥5<sup>9</sup> Network Size</b>	
Back Standalone 1-20 nodes 21-100 nodes 101-200 nodes 1001 2000 nodes 1001 2000 nodes	Network Size	21-100 nodes
1-20 nodes 21-100 nodes 101-200 nodes 1001-2000 nodes 1001-2000 nodes	Paak	Standalone
21-100 nodes 101-200 nodes 201-1000 nodes	DdCK	1-20 nodes
101-200 nodes 201-1000 nodes		21-100 nodes
201-1000 nodes		101-200 nodes
1001 2000 podeo		201-1000 nodes
1001-2000 flodes		1001-2000 nodes

#### Figure 6: Network size configuration.

- 2) Sensor configuration. Each type of datalogger has its own parameters for configuration:
- VW datalogger (Figure 7): activation of channels, sampling rate interval and VW sweep frequency for each sensor. For more information on the configuration, see Section 3.1.

<⊉5 <sup>©</sup> Sensor Configu	ration
Sampling rate	30 min
Channel 1	On
	Sweep C 1400-350
Channel 2	Off
	Sweep C 1400-350
Channel 3	Off
	Sweep C 1400-350
Channel 4	Off
	Sweep C 1400-350
Channel 5	Off
	Sweep C 1400-350
Custom start (Hz)	1400
Custom end (Hz)	3500

Figure 7: Sensor configuration options for LS-G6-VW-5 ch.

 DIG datalogger (Figure 8): sampling rate, communication protocol with sensors (from given options) and bus addresses of the sensors (if connected through RS485 by digital bus). Be aware that all the readings are kept according to the bus addresses introduced. Therefore, the number of columns of data will equal the records indicated by the inserted addresses, and not necessarily be the same as the real number of sensors connected. If you lose track of the different addresses over time, we strongly recommend a factory reset. The last configuration is saved in the datalogger.

Sampling rate	5 min	
Protocol	RST	
Addresses (separated by comma)		
26,27,28,29,30,31,32	2,33,34,35,36,3	7,38,39,
Be aware that all the recor you change the configurat in the same order than the don't keep track of the diff we strongly recommend a configuration is saved in t	ded readings are k ion. The readings inserted addresse erent addresses o factory reset. The he datalogger.	ept even i are stored es. If you ver time, last
	figuration	
Set con		

Figure 8: Sensor configuration options of LS-G6-DIG-2 ch.

• ANALOGUE datalogger (Figure 9): this datalogger supports six different analogic sensor types: voltage, full Wheatstone bridge, thermistor, current loop, PT100,

potentiometer. The interface for the sensor configuration in the Setup wizard requires the user to choose between the different sensor types in each channel (Figure 9a). For each specific sensor type, the details of the sensor wiring appear on the screen, and the configuration parameters (specific for each sensor type) have to be selected by the user (Figure 9b). Each channel can be configured independently, with specific requirements for each sensor (sensor power, warm up times, etc.).



Figure 9: Sensor configuration options of LS-G6-ANALOG-4ch

**3) Sensors data.** A reading of the active channels is displayed (Figure 10). In this stage, the user can see the readings of the sensors in this specific moment, to check if the sensors have been properly configured.

Note that this action may take some time, depending on the sensor, and particularly so when there are strings of digital sensors connected to the RS485 port of LS-G6-DIG.

∃ <b>)_5</b> <sup>9</sup> Sensors data	S
Sampling rate	30 min
Barometer	1012.2 mbar
<b>Channel 1</b> Sweep C	1630.783 Hz 4294967.5 ohms
Back	Next

#### Figure 10: Data readings of active sensors.

4) Radio configuration. This is the panel where radio configurations are set. You are required to set the correct region and country to comply with local regulations. See Table 9 of this user guide for the radio modes and configuration details. The network is identified by a Network ID, and protected with a password. All dataloggers and the gateway of an installation need to have identical settings (region and password). The default credentials of the radio network are specified in the Gateway Information Sheet (Figure 11).

The advanced options should not be changed in the majority of installations. For more details on the advanced options, check Section 4 of this manual.

کے 🖪 کے Radio Configurat	🕩 🎽 💄 11:55 a.m.
Radio enabled	On
Region	Europe
Edit network ID and	Europe
password	Malaysia
Network ID	FCC
Password	923A-Legacy
Advanced options	923A
ETSI limit duty cycle	923P
Max. spreading factor	Singapore
ADR	On
Transmit power	14 dB

Figure 11: Radio configuration screen.

Note that in order to simplify the datalogger configuration tasks, especially in large installations, the network ID and password of the last datalogger configured are saved into the Android app. The option of editing them has to be activated by the user, otherwise the credentials introduced in the configuration of the datalogger will be the ones that were introduced the last time the Android app was used.

- 5) Radio signal coverage test (only for radio models). Once the gateway is configured, a signal coverage test can be peformed (Figure 12). This test will check for correct connectivity between the datalogger and the gateway. Some test packets will be sent by the datalogger, and then the Android app will check on the gateway (using the Internet connection) for the reception of these packets. Hence, the test will check for:
  - Correct gateway operation and communication
  - Correct radio configuration on both gateway and datalogger (including matching region and ID / password configurations)

• Quality of the signal received by the gateway from the datalogger For the results of this test to be immediately displayed in the Android device, the gateway needs to be installed with a working Internet connection, and the Android device also needs to be connected to the Internet. This is what we call an "online test".

In order to perform an online test, the Dlog app needs to be supplied with the gateway's serial number and remote access password.

The remote access password is used to protect access to the gateway from the local network or the Internet. It is separate from the radio network password, even though it's set to the same value by default.

The gateway ID and default password are specified in the Gateway Information Sheet. Before starting the test itself, the gateway connectivity is checked, and in the case of any problem with the credentials an error message will appear. The displayed results are listed for each Spreading Factor (SF). The SF represents a way of modulating data. The gateway is capable of receiving all frequencies with several SF's at the same time. The lower the SF number is, the shorter the message, thus more messages can be sent on the network. The SF is proportional to the distance between datalogger and gateway: higher spreading factors are capable of transmitting data at higher distances, while lower spreading factors reach lower distances.

During the radio signal coverage test, the datalogger sends 5 or 10 packages of data at SF7 to SF12. The number of data packages that reach the gateway can be viewed in the results in order to ensure correct communication. The Australian version of the radio works differently, see section 4 of this manual.

When doing the Radio signal coverage test, the position of the Android device is kept (if the user gave permission to the app to access to the GPS data), and a security token number identifies each test.

If the gateway and/or the Android device don't have Internet connectivity during the test, the online test will fail (since it will have been impossible to contact the gateway over the Internet), and you will need to perform an "Offline test". In this mode however, the results of the test cannot be displayed in the Android device. The security token number identifies each test. You need to write down the token number along with a description of where and under what conditions the test was taken. You will have to check the results of the coverage test on the gateway's web interface (under network $\rightarrow$ Signal coverage test map  $\rightarrow$  Download all tests of this network).

A coverage test is considered correct if any of the Spreading Factors are able to deliver at least half the packets sent.

Note that performing the Radio signal coverage test takes approximately 2 minutes.

a)

b)

adio signal coverage		ار Radio signal coverag	je
ay ID		Date	
password		Token	
est - Perform the coverage sults from the gateway. Th	e test, but don't ne results can be	Node ID	
later at the gateway inter	face.	Network ID	
Back	Next	Latitude	
ffline test	Skip	Longitude	
		SF7	
		SF8	
		SF9	
		SF10	
		SF11	

Figure 12: Radio signal coverage performed at the end of the datalogger setup (using the Setup wizard).

## 2.4. Gateway installation

#### 2.4.1. Gateway overview

Dataloggers equipped with a radio communication system can transmit their readings to the gateway, and make them available for real-time access. Readings can be accessed over the Internet, via a private network, or stored on the gateway for local retrieval.

The LS-G6 Gateway (Figure 13) is made of a high-impact resistant polycarbonate, engineered to withstand harsh industrial and outdoor environments. It offers an excellent flammability rating, good UV and chemical resistance, and is rated IP67.

We advise that the gateway should be setup and configured in an office environment, rather than going through the startup procedure in an outdoor or industrial environment.



Figure 13: LS-G6 Gateway, with all the parts indicated.

The LS-G6 Gateway is composed of:

- 1. The Casing
- 2. Cable gland for RJ45 PoE, or DC Power cable
- 3. N connector, for the sensor network radio antenna
- 4. Pressure stabilizer for protection against condensation
- 5. Sensor network radio antenna, with N connector
- 6. The mounting kit
- 7. A PoE injector, and its power supply cable

The gateway casing can be opened (Figure 14) by putting a flat-head screwdriver in the small holes on either side of the door. You will need to open the gateway to perform the initial installation and configuration procedure.



Figure 14: LS-G6 Gateway opened.

Note that PoE power supply should be installed inside a box or indoors, since it is not waterproof.

#### 2.4.2. Powering the Gateway

The gateway can be powered by either PoE (Power over Ethernet), or via DC in. Only one power source is necessary. The nominal power consumption is about 3.2W (270 mA at 12V); peaks are up to 3.84 W of consumption, while idle is 2.16 W.

- Power through PoE
  - The PoE in the LS-G6 Gateway is IEEE 802.11af compliant. It is supplied with a compatible PoE power supply.
  - On the gateway side, the Ethernet cable (not included) must first be inserted into the case through the cable gland. Then, the cables must be unshielded and stripped, and connected into the terminal blocks in the correct order, as described on the Figure 15.



Figure 15: Detail of the connections for the Power through PoE.

Note that when the gateway needs to be grounded, a suitable Ethernet cable (shielded, Figure 16a) should be inserted through the cable gland. The shield of the cable must be clamped in the "earthing clip" like in the Figure 16b to get good earth shielding.





Figure 16: a) Section of shielded Ethernet cable; b) Detail of the connection for the Power through PoE using a shielded Ethernet cable.

- o The cable gland allows external cable diameter from 4 mm to 8 mm.
- On the other side of the PoE cable, the RJ45 connector must be inserted into the PoE injector. The PoE injector must be connected to 230VAC.
- The RJ45 cable must be wired according to the T-568A/B specification (Figure 17).

Note that a suitable weatherproof Ethernet cable should be used if the gateway is going to be placed outdoors (e.g. Ubiquity TOUGHCable). Alternatively, a normal Ethernet cable could be used in combination with a protection tube.



Figure 17: Wiring of the cable at the RJ45 connector (following T-568A/B specification) to be inserted in the PoE Injector.

• The gateway can also be powered with a DC power supply, such as a solar panel. The input voltage range is 11 to 30 VDC. • On the gateway side, the cable must first be inserted through the cable gland. The DC in is the terminal block shown as in Figure 18.

Note that if the gateway is powered using a generator or another source that may induce surges or spikes, a voltage stabilizer may be installed in the power input of the gateway.



Figure 18: DC terminal block.

• The cable gland allows for an external cable diameter from 4 mm to 8 mm.

Note that when powering out the gateway, the shutting down process takes some time. Therefore, even if the power is disconnected, the gateway may still be active.

#### 2.4.3. Mounting of the enclosure

The gateway enclosure comes with a mounting kit, which is designed for various configurations:

• Pole mounting by U-bolt (Figure 19)



Figure 19: Gateway mounted on a pole.

• Wall mounting (Figure 20)



Figure 20: Gateway mounted on the wall.

• Metallic strapping mounting (tube, pipe, flue.) (Figure 21)



Figure 21: Gateway mounted on a pole.

The metallic mounting kit must be grounded for safety reasons.

The antenna must also be mounted in its place on the mounting kit (Figure 22).



Figure 22: Gateway's antenna mounting.

The supplied antenna cable must be connected to the gateway enclosure, as shown on Figure 23:



Figure 23: Connection of the antenna cable to the connector.

Finally, the antenna cable must be strapped to the mounting kit to reduce accidental wear (Figure 24).



Figure 24: Fixing of the antenna cable.

Note that the gateway does not ship with surge protection out of the box as the dataloggers do. However, if this kind of protection is desired external devices may be used (Ethernet Link and Antenna Link). Contact Worldsensing technical support for further information.

#### 2.4.4. SIM Card

If the gateway is meant to use a GPRS/3G connection, you will need to insert the SIM card in its place (Figure 25).

To insert a SIM card:

- Open the gateway enclosure, using a flat-head screwdriver
- Push the SIM extraction button, using a small screwdriver, or the point of a pen
- Put the SIM in the tray, with the contacts facing out
- Put the tray back into the gateway



Figure 25: SIM card slot. Extraction button indicated.

#### 2.4.5. Ethernet connection

If the gateway is meant to be connected to the Internet by Ethernet cable, this will be through the PoE injector (Figure 26).

Note that Ethernet cable should be connected before plugging in the PoE injector to 230VAC. Once the gateway is initialized, Ethernet connection should be established in order to avoid problems with the default Internet access configuration (see section 2.5.2.2.).



Figure 26: PoE. Left port (Data & Power Out) is for the power cable and right port (Data In) is for data transmission.

## 2.5. Gateway configuration

Configuration is done with a desktop or laptop computer. The LS-G6 Gateway provides a web interface for all configuration and data retrieval tasks. The interface is accessible through **any** of the gateway's network connections, which will be explained in this section.

## 2.5.1. Connecting to the Gateway

#### 2.5.1.1. Local administration interface

In order to connect to the gateway onsite, without depending on any external network, you may use the Local administration interface. This interface provides all features of the web administration, including the network configuration and access to the LS-G6 data.

In order to use the local administration interface, you must:

- Open the gateway box, using a flat-head screwdriver
- Connect the supplied USB Ethernet adapter to the USB port on the front plate of the gateway
- Connect an Ethernet cable between the gateway's USB adapter and your laptop computer.
- Your computer must be configured to acquire an IP address automatically using DHCP
- Open the following website on your Internet Browser:
  - o <u>http://169.254.0.1</u>
  - o user: admin
  - password: VMjG6z
  - An SSL certification error will appear. This is normal, as this gateway uses a self-signed certificate for SSL authentication. Add a security exception

for this certificate so the connection is allowed. Check your browser's documentation for instructions on how to do this.

The Local administration interface should be used for:

- Initial configuration of a new gateway
- Onsite data retrieval and gateway configuration of a gateway without an internet connection
- In case the remote access password is forgotten. The local administration interface has a fixed password, which cannot be changed

#### 2.5.1.2. Remote Access connection

If the gateway has a SIM card or it is connected to a router through Ethernet, the remote access to the gateway is habilitated.

## 2.5.2. The Gateway's configuration and data access interface

In order to access the gateway's web configuration interface, you need a working network connection to the gateway. There are 3 access methods to the interface:

- Using the Local administration interface
  - Explained earlier in this chapter, the local administration interface is meant to be used for initial configuration of the other interfaces, and onsite access to the gateway
    - The credentials for local access are fixed and cannot be changed
- Using the public network interface
  - If the gateway has a working network interface (Ethernet or 3G) and its public IP is known, it's possible to access the web interface through it.
  - The password for this type of access is the remote web access password.
    - The default remote web access password is printed on your gateway Information Sheet
    - The password can be changed in the web configuration interface
- Using the Loadsensing Remote Access Service
  - If the gateway has a working Internet connection (through Ethernet or 3G), it's possible to use the Loadsensing Remote Access Service.
  - This service allows secure remote access to a gateway using an easy address, even if the network is inside a private network or is connected through a 3G connection.
  - The remote access address for any given gateway is http://loadsensing.wocs3.com/XXXX, where XXXX corresponds to the gateway's serial number.
  - $\circ$   $\;$  The password for this type of access is the remote web access password.
    - The default remote web access password is printed on your Gateway Information Sheet
    - The password can be changed in the web configuration interface

#### 2.5.2.1. Networks

The first page shown when entering the gateway's Web Configuration Interface shows the network ID and three different menus: networks, status and configuration. In case that the network ID has been changed for a specific gateway (the same serial number), several networks will appear in this tab, under different IDs. A personalized name may be given

to the network under the feature "Name". Finally, the number of dataloggers, both active and inactive are shown, and displayed in green or red according their status (active / inactive).

When entering the network, several features of the nodes are visible: status, model, serial number. Serial and node ID coincide by default but ID may be changed (Figure 27). Through this page it is possible to:

- Download the compacted .dat / .csv files of the data collected by the network (raw data or engineering units (see section 2.6 for further information).
- View the signal coverage test map, where test results are geographically plotted.
- See datalogger basic information: status, ID, serial number, model
- Access all the menus of the gateway configuration interface.
- Visualize data sent from the dataloggers. Also, the messages lost and received by the gateway are counted (under status tab). The green number indicates the messages received, the red number corresponds to the lost radio messages and the orange number to messages lost due to gateway power interruption (Figure 28).
- Remotely change the sampling rate of the dataloggers \*

\*This feature requires minimum gateway software version 1.7. and minimum dataloggers firmware version 2.15. Please contact Worldsensing for further information on firmware and software versions.

20	adsensing	Networks	Status - Configuration -			
N / Net	etwork: Norks/13004	I'H 🖍				
Co	mments					
Compacted readings CSV files		CSV files	± compacted-readings-13004-current.dat + More			
Co	Compacted engineering units CSV files		± compacted-eng-13004-current.dat + More			
Co	Compacted custom CSV files		♣ compacted-custom-readings-13004-current dat + More			
al S	ignal coverage test i	map				
N	odes Q					
	1				0 nodes	selected of 7
	Id	Name		Status	Model	Serial
8	1140 🕑 30m	piez 302+640 SE		Ok	LS-G6-VW-5-EU	1140
8	1312 🛇 30m	piez 301+390 E		Ok	LS-G6-VW-5-EU	1312
	1678 🛇 30m			Ok	LS-G6-VW-5-EU	1678
8	1683 🕑 30m	1683 © 30m piez 301+100 W, BHE 301+250 W, piez 301+390 W, piez 301+250 W, pie		Ok	LS-G6-VW-5-EU	1683
65	2031 © 30m			Ok	LS-G6-VOLT-4-EU	2031
۲	2742 🕑 30m	piez 301+100 E		Ok	LS-G6-VW-1-EU	
0	2790 🛈 30m					2742
		piez 301+250 E		Ok	LS-G6-VW-1-EU	2742 2790

## Figure 27: Initial page of the gateway. This is the first page when entering the Web's Configuration Interface.

Status	
Status	Ok
Last status change date	2016-01-13 01:55:13 AEDT
Monitoring status emails	✓ Yes
Messages received: today	368 1
Messages received: 1 day ago	107 5 2
Messages received: 2 days ago	74 1
Messages received: 3 days ago	0 0
Messages received: 4 days ago	0 0
Messages received: 5 days ago	0 0
Total number of messages since gateway installation	549 7 2
	Note: all messages not received are stored in the node, and can be retrieved with the

Note: all messages not received are stored in the node, and can be retrieved with the dlog app

Figure 28: Summary of the datalogger status and the history of received / lost messages.

#### Remote change of sampling rate

- The sampling rate can be remotely changed for one or several dataloggers.
- When the check box in the left of the corresponding line is selected and "Change sampling rate" applied, the new sampling rate option can be selected from a pop up menu.
- Once done and changes saved, a clock icon with the value of the new sampling rate next to it will appear on the ID column of the node.
- When it appears with an orange label, this means that the change has still not been applied.
- If the orange label disappears, this means that the change is effective.
- While the orange label is active, the changes can be cancelled.
- If the user tries to introduce a sampling rate not suitable according to the slot times required for the network, a message will appear where the user will have to accept that he/she understands the risk (Table 8).

By changing the sampling rate remotely, the user allows the gateway to have the information about when is it going to receive data from the sensors. The advantage of letting the gateway have this information is that the compacted files (including data from the entire network) can be closed and upload to the FTP as soon as the sampling of the entire network is completed.

#### 2.5.2.2. Status

In the status tab, the user can view the gateway status or the Logs of the gateway.

#### > Gateway status

In the gateway status menu, the following information is displayed (Figure 29).

- General Information
  - Gateway serial number
    - Shows the hardware's serial number. This value cannot be changed.
  - o Gateway Model

- Shows the hardware model.
- Firmware version
  - Shows the current Firmware version. The gateway's firmware can be remotely updated by Worldsensing Technical Support, as long as the gateway has an Internet connection, and remote access is working (see below)
- o Date
  - Shows the current date, according to the gateway's internal clock, always in UTC
- o Uptime in minutes
  - Shows the time in minutes since the gateway was connected or rebooted
- o Input voltage
  - Shows the voltage that powers the gateway. This reading has a precision of +/- 0.35V
- o Voltage history
  - Link to a .csv file that includes the historical records of the voltage, every 15 minutes. Not separated by months.
- Application status
  - o Network ID
    - Shows the current sensor radio network ID
  - Internet connection (ping)
    - Shows if the gateway is able to connect to the Loadsensing server, in order to check for connectivity.
    - Check the "Internet configuration" section for more information on this check.
  - Status reporting
    - Shows if the gateway is able to send status reports to Worldsensing.
    - These reports are sent via HTTP (port 80) to loadsensing.wocs3.com, and will provide information on the gateway's status to Worldsensing Technical Support
  - Remote access
    - Shows if the gateway is able to open a remote access connection to the Worldsensing server.
    - This service uses a TCP connection to loadsensing.wocs3.com, on port 22
    - The remote access mechanism is used:
      - To provide the Loadsensing Remote Access Service, which allows remote access to the Web Configuration Interface
      - To provide remote access capability to Worldsensing Technical Support, which allows for remote support and remote updates of deployed gateways
- Network information

Shows the parameters of the currently active network configuration

- Selected interface
  - Shows the connectivity to the Internet that has been selected by default or manually.

- o Ethernet status, IP and Netmask
  - Shows the status of the Ethernet interface (up/down), and the current address if there is one
- o GPRS/3G status and IP
  - Shows the status of the GPRS/3G interface (up/down), and the current address if there is one
- o Default gateway and DNS servers

•

- GPRS Modem Info
  - o Status
    - Indicates if the current status of the GPRS modem is correct.
  - o IMSI
    - Identification number of a certain user in a cellular network.
  - $\circ \quad \text{Operator} \quad$ 
    - Telecommunication operator used for the GPRS modem.
  - o Roaming
    - Indicates whether the itinerancies of data in roaming mode is activated or not.
  - o Mode
    - Indicates the technology (algorithm) used in telecommunications to define the channels and bandwidth to be used (CDMA or WCDMA).
  - o Signal
    - Indicates, in percentages, the signal coverage of the telecommunications operator.
  - o LAC
    - Location area code, a number that allows identification
  - o Cl
- Cell identity

loadsensing 4 Networks Status - Configuration -

## Gateway status

/Gateway status

#### **General Info**

Gateway serial number Gateway Model Firmware version Date Uptime (minutes) Input voltage Voltage history

13004 LS-G6-GW-EU 1.10 Wed Jun 22 13:26:34 UTC 2016 666 12.2394 V gwVoltages\_1.csv

#### Application status

Network ID Internet connection (ping) Status reporting Remote access

#### Network Info

Selected interface Ethernet Status Ethernet IP Ethernet Netmask Gprs/3g Status Gprs IP Default Gateway Primary DNS Secondary DNS

CI

Gprs/3G Not connected none none Up 10.54.83.33 0.0.0.0 85.62.229.133 85.62.229.134

Connection OK

Connection OK

13004 Ping OK

#### **Gprs Modem Info**

Status Valid service IMSI 214031530050566 Operator Orange Roaming Not roaming Mode WCDMA Signal 77 % 0 LAC 0

#### Figure 29: Gateway status page.

#### ≻ Logs

In the Logs page, the status actions are reported and the user can select by dates the logs to be displayed.

#### 2.5.2.3. Configuration

The configuration tab shows the different configuration options.

#### General

The gateway has an internal clock configured in UTC, however, the user can introduce the time zone in the gateway software interface. By doing so the user will be able to retrieve and visualize the data in local time.

#### > FTP client

In the configuration tab, the user can configure an FTP client, in order to push the data stored every 15 minutes in the gateway automatically to the server (see 2.6 Data visualization and retrieval).

Note that 3 different protocols are available (FTP, FTPS and FTPS (ignoring self-signed certificates)). FTPS mode requires that the server has a security certificate, while FTPS ignores the presence of this certification.

The output of the FTP upload can be a new file every time that there is an upload, or alternatively a modification of the monthly generated file.

Compacted CSV

This feature allows the user to create a self-configured csv file, with the desired columns, customized header names, column order, etc. (Figure 30). The maximum number of columns is 520 (maximum supported by Excel). Once saved, a csv file called "compacted-custom-readings-XXXX-current.dat" (XXXX being the network ID) is created. Every time a new compacted csv file is created, the old one is saved with a variation of the suffix "current" by "yyyy-mm-changeX". This file appears in the Networks main page, where the files to download are visible.

Load:	sensing <sup>©</sup>	Networks Status -	Configuration +				
Cor / Compact 13004	Compacted CSV <sup>/ compared CSV</sup> 13004 •						
Node	1140	Column At	mPressure-1140-in-mb • Header	name AtmPressure-1140-in-mbar Add			
	Column	Node	Data source	Header name			
1	1	1140	p-1140-Ch1	p-1140-Ch1	â		
1	2	1312	p-1312-Ch1	p-1312-Ch1	â		
1	3	1678	p-1678-Ch1	p-1678-Ch1	â		
1	4	1683	p-1683-Ch1	p-1683-Ch1	â		
1	5	2031	eng-2031-Ch1	eng-2031-Ch1	â		
1	6	2031	eng-2031-Ch2	eng-2031-Ch2	â		
1	7	2742	p-2742-Ch1	p-2742-Ch1	â		
1	8	2790	p-2790-Ch1	p-2790-Ch1	â		
Save							

Figure 30: View of the tool to create a self-configured csv file of the network data.

#### Modbus gateway

This feature will allow access to the data from the Loadsensing sensors via Modbus TCP protocol. The Modbus address maps can be viewed in the Annex 8.

#### > Internet

In the configuration tab, the user can also change the Internet connectivity details (Figure 31). By default, this is set in the automatic mode (Figure 31).

It is possible to select a custom NTP server (from a local network). A custom SMTP server can also be configured.

	Networks	Status 🗸	Configuration -			
Internet						
/ Internet						
Activate network Wate	:hdog					
Disable the Network Wat The network watchdog is a freeze or other network en It will reboot the gateway	Disable the Network Watchdog if this gateway does not have an internet connection The network watchdog is a mechanism to reboot the gateway in case of a network failure, modem freeze or other network error condition. It will reboot the gateway after 40 minutes of consecutive unsuccessful Internet connection attempts.					
Network connection:						
<ul> <li>Automatic (Ethernet if</li> <li>Manual Configuration</li> </ul>	<ul> <li>Automatic (Ethernet if connected, gprs/3g otherwise)</li> <li>Manual Configuration</li> </ul>					
NTP server (to synchron	NTP server (to synchronize the gateway's clock):					
<ul> <li>Default (pool.ntp.org)</li> <li>Custom</li> </ul>						
SMTP server:						
● Default (Internet servic ○ Custom	:e)					
Changes will not be applie	d until next de	vice reboot.				
Save configuration						



- Network Watchdog
  - The Network Watchdog is the mechanism that checks whether the Internet connection is working properly.
  - This mechanism checks Internet connectivity every minute, by sending a ping request to loadsensing.wocs3.com
  - If the gateway is unable to communicate with the server for 40 minutes, it will assume there is a problem with the connection, and reboot the gateway
  - The Network Watchdog must be disabled if the gateway does not have an Internet connection
    - If a gateway with no Internet connection is left with the Network Watchdog enabled, it will start a reboot cycle every 40 minutes. This will lead to sensor data loss, as data entering during the reboot cycle will not be stored.
  - The Network Watchdog is enabled by default
- Network connection
  - o Automatic (default)
    - In automatic mode, the network connection mode is automatically configured upon gateway startup
    - If a connected Ethernet cable is detected, an Ethernet connection with DHCP will be used
      - An Ethernet cable is connected if there is some kind of network equipment (for example a router or a switch) on the other side of the cable. The PoE injector doesn't count.
    - If no Ethernet cable connection is detected, the GPRS connection will be launched, with its configured parameters

Manual configuration (Figure 32).

#### Network connection:

- Automatic (Ethernet if connected, gprs/3g otherwise)
- Manual Configuration

• Gprs/3G

- Ethernet with DHCP
- Ethernet with static IP

#### Figure 32: Options for manual configuration.

This setting will override auto-detection, and always launch a GPRS/3G connection

- Ethernet with DHCP
  - This setting will override auto-detection, and always launch an Ethernet connection, getting the configuration automatically through DHCP
- Ethernet with Static IP
  - This setting will override auto-detection, and always launch an Ethernet connection.
  - In this mode, you need to manually set all parameters of the network configuration:
    - o IP Address
    - o Netmask
    - Default gateway
    - o DNS servers
- NTP server (to synchronize the gateway's clock)
  - The NTP server by default has to be accessible through the Internet, so normally, if the gateway is connected to the Internet, it is common to use an NTP server.
  - Even in situations where the gateway is not connected to the Internet, it is still common have a custom NTP server, which may be in a local server.
- SMTP server
  - The default option is to use an SMTP server through the Internet. In the case of the gateway not being connected to the Internet this option would not be valid.

A custom SMTP server can be defined if the gateway is not connected to the Internet, however the monitoring e-mails are still required. A custom SMTP server can be placed in a local server.

#### ≻ GPRS/3G

The GPRS/3G configuration tab (Figure 33) contains some configuration parameters specific to this type of connection.

	Networks	Status <del>-</del>	Configuration -		
GPRS / 3G	ì				
/ GPRS / 3G					
<ul> <li>PIN Off (Sim card is unlocked)</li> <li>PIN On (Sim card needs PIN code)</li> </ul>					
<ul> <li>APN Auto selection (w</li> <li>Manual APN Configur</li> </ul>	vill select based ation	d on the SIM	I card operator)		
Username:					
Password:					
Changes will not be applie Save configuration	ed until next de	evice reboot.			

Figure 33: Settings for the configuration of the GPRS/3G connection.

This configuration will be applied whenever a GPRS/3G connection is used, regardless of whether it was the result of an automatic or manual configuration in the Internet tab.

- PIN setting
  - Off (default)
    - In this mode, the gateway will not try to unlock the SIM card.
    - If the SIM card is protected by a PIN code, the GPRS/3G connection will fail.
  - o On
    - This setting will allow you to enter the PIN code for use with a PINlocked SIM card.
    - Be careful not to boot the gateway with a PIN-protected SIM card with the wrong PIN set here. The gateway will automatically try unlocking the SIM, and exhaust the three possible attempts.
    - There is no way to enter the PUK code in the gateway. If your card gets PUK-locked, you will have to unlock it using a mobile terminal.
- APN settings
  - o APN Auto selection (default)
    - Every mobile operator requires the setting of a specific configuration for connection to its network.
    - The LS-G6 Gateway features a database of the correct configurations for hundreds of operators around the world. This setting will try to configure the connection automatically based on the SIM card that is inserted.
    - This setting may fail if your operator is not in the database, or your configuration is non-standard.
  - o Manual APN configuration

- This setting will allow manual input of the mobile operator configuration values.
- Use this setting if auto selection didn't work for you, or you need to input specific, non-standard configuration values.

#### Remote access

This page will allow you to change the password used for remote access to the Web Configuration Interface (Figure 34).

The new or the initial provided password will be required to access the gateway either through the public network interface, or through the Loadsensing Remote Access Service.

Be careful on setting weak passwords. This will make your gateway accessible from anywhere on the public network, or anywhere on the Internet if you have an Internet connection.

In order to change the password from the public interface or from the Remote Access Service, you will need to input the previous password. This is not required if you are connected through the local administration interface.

The default factory password is printed on the Gateway Information Sheet. Once you change the password, there is no way to recover it.

In case of a lost or forgotten remote access password, you will have to use the Local Administration Interface to change it to a known one (section 2.5.2).

LoadSenSing V Networks Status - Configuration -						
Remote access						
This will change the remote password for this gateway. It's the password used to access his website from:						
<ul> <li>The gateway's Ethernet or Gprs/3G public IP</li> <li>The loadsensing remote access service, as long as the gateway has an internet connection.</li> <li>Set a strong password as this password is used to make your gateway accessible from the Internet</li> <li>The remote access URL for this gateway is         https://loadsensing.wocs3.com/13004/     </li> </ul>						
The factory default remote administration password can be found in the Gateway Information Sheet						
Admin password						
This is the password for the "admin" user						
Current password: Note: The current password is not necessary if you are logging in through the local administration interface						
New password:						
Change Admin password						
View only password						
This is the password for the "viewonly" user						
The viewonly user can retrieve information from the gateway, but cannot change any configuration parameters. It is not enabled by default, and must be set a password by administrator before it can be used.	7 the					
User enabled:						
New password:						
Repeat new password:						
Set viewonly configuration						

#### Figure 34: Remote Access tab, inside the gateway interface.
#### View only password

This view is designed to provide access to users that are only allowed to see the data collected in the network, but are not allowed to change any of the configuration parameters. The "view only" user has to be defined by the administrator.

#### > Radio

This page allows you to configure the parameters of the Wireless Sensor Radio Network (Figure 35). There are three different gateway models, according to the geographical areas in which they'll be placed. In addition, depending on the country's regulations, the radio configuration will be set specifically.

Note that for some countries, an advanced menu can be displayed. This refers to the possibility of choosing different channels through which data can be sent, in each spreading factor. This will be useful for projects with many dataloggers (hundreds), sampling at a high rate. Some dataloggers would be set at one group (and also one gateway) and some other nodes at a different frequency group (and also a second gateway configured to this other group) and in this way possible collision can be avoided.

# Note that if the user changes the default configuration of the advanced options, these should also be changed in the datalogger configuration (see sections 2.3. and 4).

In order for the LS-G6 dataloggers to be able to connect to this gateway and send data, both the gateway and all participating dataloggers need to be configured with the same parameters.

- Network ID
  - o A numeric identifier of the wireless sensor network
  - Set by default to the serial number of the gateway
  - Should only be changed it if you're replacing a gateway and don't want to reconfigure all dataloggers in the network
- Network Password
  - This password is used to encrypt all data in transit on the Wireless Sensor Network.
  - The default factory password is printed on the Gateway Information Sheet.
  - Once you change the password, there is no way to recover it. You will have to change it to a new one in the gateway as well as in all dataloggers in the network.

	Networks	Status -	Configuration -	
Radio				
/ Radio				
Change country and frequ	ency range:			
<ul><li>These parameters n</li><li>You must choose th</li></ul>	nust match thos ne correct count	e configured try where thi	on all sensors in the s equipment will be	network used. This device may otherwise fail to comply with local regulations
<ul> <li>Australia</li> <li>FCC(America) show/hide frequencies</li> </ul>	ency selection	(advanced)		
Changes will not	be applied until	next device	reboot.	
Change Country a	nd frequency			
Change Radio Network II	) and password	l for this gate	way:	
<ul> <li>These parameters n</li> <li>The network ID ma</li> <li>The network passw</li> <li>place, you will nee</li> <li>The network passw</li> </ul>	nust match thos tches the Gatev ord cannot be r d it to configura ord is case sens	e configured vay ID by de etrieved from e the Loadser sitive	on all sensors in the fault. Do not change a the gateway, <b>write</b> using nodes, and in o	network unless you know what you're doing <b>it down and keep it in a safe</b> ase you need to replace this gateway
Network ID: 1310	4			
Network Password:				
Changes will not be appli	ed until next de	vice reboot.		
Change Network ID and pa	assword			

Figure 35: Radio configuration tab, inside the gateway interface.

#### > Delete all

In order to delete all the data contained in the gateway (but not all the configuration), the user has to access the tab "Delete all data" (Figure 36) and follow the instructions.

	Networks	Status <del>-</del>	Configuration +	
Delete all				
/ Delete all				
This will DELETE ALL DATA	from your gate	eway. <b>This pr</b>	ocess cannot be u	ndone.
It will:				
<ul> <li>Erases all Loadsensi</li> <li>Erase all logs</li> <li>Reset the FTP client of Reset the monitoring</li> </ul>	ng nodes data config emails list	on this gatew	ay: CSV files, formul	as, comments, names
It will NOT:				
<ul> <li>Change the web accord</li> <li>Change the radio pase</li> <li>Change the network</li> </ul>	ess passwords ssword or ID settings (eg. gp	rs or etherne	t settings)	
Are you sure you want to de	elete all data? T	o confirm, wr	ite " <b>Yes, delete all</b> " (	on the box below to confirm data deletion, and click on "Confirm".
Yes, delete all				

Figure 36: Delete all tab, inside the gateway interface.

#### > Reboot

After changing some of the configuration parameters of the gateway, it needs to be rebooted to apply the changes (Figure 37).



Figure 37: Reboot tab, inside the gateway interface.

# 2.6. Data visualization and retrieval

For all models, data files (.csv) can be retrieved by USB cable from the datalogger using the OTG USB cable, through the Android application DLOG. The option for downloading data is in the "Sensors data" tab, using the arrow pointing down. The data files can also be sent via email.

For the radio models only, the data is sent to the gateway and is retrieved from there. In the gateway it is possible to display the data collected in the nodes, transformed into engineering units and with a graphical interface. The storage capacity of the gateway is 8 GB.

For the transformation into engineering units, the user has to introduce the required formula, depending on the sensor. In the Last readings tab, when selecting a node, a gear icon is placed to the far right of each channel's last reading (Figure 38). By clicking this icon, the menu to edit the formula corresponding to the sensor is displayed (Figure 39).

The formula has to be selected from a drop-down menu of several Linear and Polynomial formulae available.

Channel	Thermistor (Ohms) 屋	Frequency (Hz) 📈	
1	4294967.295	1529.097	٥
Pressure (mBa	r) 🛃	Pressure (kPa)	
1011.1		101.11	\$

Figure 38: In the "Last readings" tab, a gear icon appears on the right, for editing the formula of the sensor.

Engineering units
Networks / 13004 / Node 1140 / Engineering units
Observal 1
Channel 1
Polynomial A with compensation
$\begin{split} P &= AR_i^2 + BR_i + C + K(T_i - T_0) - F(S_i - S_0) + D \\ \text{P: Converted data in units} \\ \text{R: Courrent Reading in digit during observation} \\ \text{T: Temperature during the observation} \\ \text{S: Current barometric pressure in kPa} \end{split}$
Units: Magnitude that is measuring the sensor (ie: mBars, mm)
kPa
A: Polynomial gage factor (from calibration)
4.6290E-08
B: Polynomial gage factor (from calibration)
-1.5185E-01
C: Polynomial gage factor (from calibration)
9.6681E+02
K: Thermal factor in units/°C
0.015
Ta: Temperature at the time of taking zero reading in °C
20
E: Conversion factor in units/kPa
1
S-: Parametria pressure at time of installation in kPa
101.1
D. Offect in units
Thermitter VSI4400E (PC)
$T = \frac{1}{A + B(LnR) + C(LnR)^3} - 273.2$ T: Temperature in °C LnR: Natural log of thermistor resistance A: 1.4051 x 10 <sup>3</sup> B: 2.309 x 10 <sup>4</sup> C: 1.019 x 10 <sup>7</sup> Note: Coefficients calculated over the -50°C to +150°C span.

Figure 39: Menu to edit the formulae for transforming the raw data of the sensors into engineering units.

Gateway data visualization and retrieval is possible by accessing the gateway (locally or through the server) and clicking the icon next to each header (Figure 40).

Data visualization in the charts is of only the last 400 readings of each sensor. In each chart, all the sensors connected to a datalogger are displayed. Some sensors may be deactivated from the chart by the user (Figure 41).

Under the Configuration tab, the time zone of the gateway can be configured. It is important for correct display of the charts, as otherwise they will be shown in UTC.

Channel	Thermistor (Ohms) 🗾	Frequency (Hz) 📈	Engineering unit	T (°C) 屋	
1	3165.588	2207.994	98.546 mm	23.7	٥

#### Figure 40: Circled in red, the icon to display the charts of each of the sensors.

	Networks	Configuration +	
Charts /Networks/ /Node	/ Charts		
	<u> </u>		110
	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~		105
1. Sep 04:00	08:00 12:0	0 16:00 20:00 2. Sep 04:00 08:00 12:00 16:00 20:00	3. Sep 04:00
		— p -Ch1 — p- ·Ch2 — p :=Ch3 — p -Ch4 — 1 3-Ch5	Highcharts.com

#### Figure 41: Example of a chart of one datalogger.

Retrieval of data can be done into two different ways:

- General network files: three .dat files are available to download (Figure 42):
  - o compacted readings of raw data from the dataloggers
  - o compacted readings in engineering units
  - o compacted custom readings (created by the "Compacted CSV" option.)

A gateway with stable Internet connection through SIM card and a single (compacted) FTP upload usually consumes in the vicinity of 150 MB/month. The FTP upload happens every 15 minutes, and if the existing file in the FTP is consistent, only new data is uploaded and either appended to the existing file or a new file is created. In the case that the file is corrupted or removed, the whole file is uploaded again, to ensure that there is always a complete copy in the server.

	Status - Configuration -		
Network: 13104			
Networks / 13104			
Comments			
Compacted readings CSV files	★ compacted-readings-13104-current.dat + More		
Compacted engineering units CSV files	L compacted-eng-13104-2015-12.dat		
II Signal coverage test map			
Nodes 🔍			
All0 nodes selected of 3			
Id	Name Status	Model	Serial

Figure 42: View of the screen where the .csv files of raw data and data transformed into engineering units (of the complete network) can be downloaded.

Note that the file where the new data is saved is called xxxxx-current.dat. The current file is prepared to support up to 520 columns.

At the end of the month, the file is closed and named xxxxx-yyyy-mm.dat (yyyy:year; mm: month). Files of past months can be retrieved by clicking "+ More" below the current file. During the process of closing the file and changing the name, there is a delay of 1.5 hours.

- Specific files for each of the nodes: two csv files are available to download (Figure 43):
  - health (containing battery in V, temperature in Celsius and uptime node in seconds)

LOADSENSING	Networks Status - Co	onfiguration 👻			
Vode 18	52 🖍				
Vetworks / 13104 / Node	1852				
Name					
nstallation date					
Comments					
/lodel	LS-G6-VW-5-FCC				
firmware version	2.15				
Serial number	1852				
Health CSV files Vibrating wire CSV	files 1852-health-20	15-12.csv 2015-12.csv			
Health CSV files Vibrating wire CSV Last readings	tiles table to be the series graphs	15-12.csv 2015-12.csv		- (20)   4	
Health CSV files Vibrating wire CSV Last readings Channel	tla52-health-20 files tla52-readings- a and Time series graphs Thermistor (Ohms) 🗠	15-12.csv 2015-12.csv Frequency (Hz) 🔀	Engineering units 🖌	T (°C) 屋	
Health CSV files Vibrating wire CSV Last readings Channel 1	± 1852-health-20 files    ± 1852-readings- and Time series graphs Thermistor (Ohms) ⊭ 4294967.295	15-12.csv 2015-12.csv Frequency (Hz) ⊭ 1571.536	Engineering units ⊭ -3.738 mm	<b>T (°C) ⊭</b> -87.5	¢
Health CSV files Vibrating wire CSV Last readings Channel 1 2		15-12.csv 2015-12.csv Frequency (Hz) ⊭ 1571.536 1584.172	Engineering units ⊭ -3.738 mm 160.158 mm	T (°C) ⊭ -87.5 -87.5	¢
Health CSV files Vibrating wire CSV Last readings Channel 1 2 Pressure		15-12.csv 2015-12.csv Frequency (Hz) ⊭ 1571.536 1584.172 Pressure (kPa)	Engineering units ⊭ -3.738 mm 160.158 mm	<b>T (°C) ⊭</b> -87.5 -87.5	0
Health CSV files Vibrating wire CSV Last readings Channel 1 2 Pressure 2 988		15-12.csv 2015-12.csv Frequency (Hz) ⊭ 1571.536 1584.172 Pressure (kPa) 98.8	Engineering units ⊭ -3.738 mm 160.158 mm	<b>T (°C) ⊭</b> -87.5 -87.5	0 0
Health CSV files Vibrating wire CSV Last readings Channel 1 2 Pressure 2 988		15-12.csv 2015-12.csv Frequency (Hz) ⊭ 1571.536 1584.172 Pressure (kPa) 98.8	Engineering units 🖌 -3.738 mm 160.158 mm	T (°C) ⊭ -87.5 -87.5	¢ ¢ T20:53:32Z
Health CSV files Vibrating wire CSV Last readings Channel 1 2 Pressure 2 988 Status		15-12.csv 2015-12.csv Frequency (Hz) ⊭ 1571.536 1584.172 Pressure (kPa) 98.8	Engineering units ⊭ -3.738 mm 160.158 mm	T (°C) ⊭ -87.5 -87.5	¢ ¢ T20:53:32Z
Health CSV files Vibrating wire CSV Last readings Channel 1 2 Pressure 2 988 Status Metadata		15-12.csv 2015-12.csv Frequency (Hz) ⊭ 1571.536 1584.172 Pressure (kPa) 98.8	Engineering units ⊭ -3.738 mm 160.158 mm	T (°C) ⊭ -87.5 -87.5 ceived on 2015-12-17	¢ ¢ T20:53:32Z

o data readings (raw data)

Figure 43: View of the screen where the data of a specific datalogger can be downloaded.

In the configuration tab, also the FTP can be configured (Figure 44). The user can specify the FTP settings and the files that they want uploaded. When the FTP is first configured in the gateway, an upload test is performed.

The files can be uploaded to the FTP:

- Separately, per node type. Files are pushed every 15 minutes, in real time.
- Compacted in one file. Files are pushed every 15 minutes; however, this option is delayed one-hour respect to the real time. The reason for this delay is that the compacted file is generated every hour, and in order to

avoid conflicts between reception of data and the file creation, the file is created with 1 hour delay. The new data can be uploaded in a separate file every new upload, or by appending the new data to the end of the existing file. The data consumption in both cases is similar.

The available protocols for the FTP are: FTP, FTPS (which requires a security certification) or FTPS (without security certification). The folder to which the data is uploaded can be directed by a relative path, or by the full path. Data can be accessed through http calls.

The way FTP upload works is like this:

1. Gateway checks which was the last data uploaded in the FTP file

2. It uploads the following data (in the same file).

3. If the gateway doesn't find the file (because it was removed) it uploads it again from the beginning of the month.

Loadsensing	Networks	Status -	Configuration -		
FIP clier	nt				
/ FTP client	Data is pushed to	the ETD ever	4 15 minutes		
Hostnama	urdumoso2.com	ule i i Pevel	y 13 milliotes		
nosuame	vuv.wocss.com				
Port number	21				
	Use anonymous	s FTP			
Username	wslhospitalet				
Password	v65531W6q3				
Protocol	FTP			٣	
FTP mode	Passive			•	
Output	Append to end o	of file		Ŧ	
Last result	<ul> <li>Succeeded on 2</li> </ul>	016-06-23 16	21:15 CEST		
Type of file	Enab	led Full pa	th (starting with /) or	r Relative path (starting with ./)	
Health					
Vibrating wire data	a 🔍				
Inclinometer data					
Volt data					
SHM data		J			
Weather data					
Compacted data		J			
Custom compacte	ed data 🛛 🗷	J			
Save and test					

Figure 44: View of the screen where the FTP can be configured.

Alternatively, the last messages received by the gateway are displayed in API format. This can be viewed under the tab "Last Messages" of the software interface (Figure 45).

Message {     "nodeModel": "LS-G6-VW-5-EU",     "commMetaData": {         "network10": "13012",         "	
{     "nodeModel": "LS-G6-VW-5-EU",     "commMetaData": {         "networkId": "13012",         "	
<pre>"macAddress": 57673283, "receivedTimestamp": "2015-09-01T09:35:20Z", "frequencyHertz": 868.85, "snr": 11, "sequenceCounter": [ 53 ], "gatewayId": 13012, "rssi": -51, "type": "longRangeRadioMetaDataV1", "sf": 12, "macType": "ETSIV1"</pre>	
	"macAddress": 57673283, "receivedTimestamp": "2015-09-01T09:35:202", "frequencyHerts: 868.85, "snr": 11, "sequenceCounter": [ 53 ], "gatewayId": 13012, "tspe": "longRangeRadioMetaDataV1", "tspe": "longRangeRadioMetaDataV1", "sf": 12, "macType": "ETSIV1" }, 

Figure 45: View of last messages received by the gateway, displayed in API format.

# 2.7. Maintenance

Proper maintenance of LS-G6 components is essential for obtaining accurate data. Equipment must be in good operating condition, which requires a program of regular inspection and maintenance. The person in charge of the logging system can carry out routine and simple maintenance. The more difficult maintenance such as datalogger calibration, datalogger performance testing, and datalogger component replacement, should be done by someone from the Worldsensing technical support team or by a certified distributor.

A station log should be maintained for each monitoring site that includes serial numbers, dates of site inspections, and maintenance performed.

#### 2.7.1. General Maintenance

- Check sensor leads and cables for cracking, deterioration, proper routing, and strain relief. Replace sensor cables if required.
- Check that the box junction and cable gland are dry and completely tightened.
- Check that the screws are correctly locked and the enclosure lid is in perfect condition.
- Check battery life periodically. Replace when less than 20% remaining.

#### 2.7.2. Periodical maintenance

#### 1 Month

- a. Monitor data values collected by the units periodically. Abnormal or out of range sensor values may indicate problems with the unit.
- b. Monthly visual inspection of the station to observe any apparent problems.
- c. Do a visual inspection of the sensors and position of boxes.

## 6 Months

a. Inspect the enclosure seal.

#### 12 Months

a. Check battery life periodically. Replace when less than 20% remaining.

#### 2-3 years

a. Battery replacement. The lifetime of the battery depends on the use of each node, number of channels, sensors, etc.

## 2.7.3. Return material authorization

Products may not be returned to WS without prior authorization. To obtain a Return Material Authorization (RMA), please contact WS technical support. After the nature of the problem is determined, an RMA number will be issued. Please write this number clearly on the outside of the shipping container. The following contact information is for international customers residing in countries served by Worldsensing S.L. directly. Worldsensing's shipping address is:

WORLDSENSING, S.L.

Aragó 383, 4th

08013 Barcelona

(Spain)

# 3. LS-G6 DATALOGGERS

# 3.1. LS-G6-VW

#### 3.1.1. Sensor connection

Most of the vibrating wire sensors can be interfaced to the LS-G6-VW.

The datalogger is supplied with cable glands (one for each channel), for the adjustment to different cable diameters.

After each terminal block is connected, taking a sensor reading is recommended in order to ensure that the connections have been done correctly. This reading should be compared with the reading of the sensor on installation with a portable readout unit, before connecting to the LS datalogger. Note that some configuration is required during the installation (see section 3 of this manual).

Cables must be connected in accordance to the following table:

Each terminal block has a group of 5 connectors.

Each group has:

- 1x Vibrating wire channel
- 1x Thermistor channel
- 1 shield terminal

An example of the connections for one terminal block (Table 1 and Figure 46) is listed below.

#### Table 1: Connections of the terminal block.

Name	Function	CH 2	
SHLD	Used to connect the sensor shield if needed	SHLD	HER
TH2-	Thermistor input 2. No polarity.	TH2-	NET
TH2+	Thermistor input 2. No polarity.	TH2+	
VW2-	Differential voltage input 2.	VW2-	
VW2+	Differential voltage input 2.	V VV Z + I	<b>Link</b>

Figure 46: Detail of a terminal block.

#### 3.1.2. Barometric measurements

The datalogger includes a barometer (BOSCH BMP180 device). It is important to avoid placing the datalogger inside any type of container. This would affect the correct readings of the barometer through the gore valve.

If the Vibrating Wire sensor requires barometric pressure compensation (such as piezometers installed in locations which can be affected by changes in barometric pressure), the current pressure readings from the barometer are usually used directly. The transformed data (compensated by the barometric pressure) is displayed if the user selects the option "Polynomial A with compensation" in the Engineering Units drop-down menu (see section 2.6).

In the case that the desired measurement is the atmospheric pressure at the sea level (commonly used in meteorology), a correction of the barometric readings is needed.

The formula for the correction of the barometric readings in order to provide atmospheric pressure at the sea level is:

$$p_{0} = \frac{p}{\left(1 - \frac{altitude}{44330}\right)^{5.255}}$$

p<sub>0</sub>= pressure at the sea level in mbars

years

years

>10

p= current pressure reading

altitude= altitude in m.a.s.l.

#### 3.1.3. Battery lifespan

The following table gives the indicative battery lifespan per channel (Table 2). User should take into account that consumption varies depending on the sensor used, the sampling rate and the environmental conditions.

		, aatarogger	e en jueng		-,	
Number	Sampling SF 7)	rate (cons	idering	Sampling SF 9)	rate (cons	sidering
sensors	30 minutes	5 minutes	30 secs	30 minutes	5 minutes	30 secs
4	>10	>10	1.2	>10	>10	7

years

months

3

Years

years.

>10

years

5 years

months

months

2

 Table 2: Indicative lifespan for LS VW-datalogger 1 ch (using 1 C-size cell) and LS 

 VW- datalogger 5 ch. (using 4 C-size cells)

NOTE: Extreme temperatures could cut down the capacity by 20 to 40%, check the specifications of your batteries. USB not used.

years

7 years

## 3.1.4. Configuration

The vibrating wire node requires configuring the sweep frequency before starting. There are several existing predefined sweep frequencies:

- Sweep Frequency A (450-1125 Hz),
- Sweep Frequency B (800-2000 Hz),
- Sweep Frequency C (1400-3500 Hz),
- Sweep Frequency D (2300-6000 Hz)
- Custom Sweep Frequency (min value: 300 Hz max value: 7000 Hz).

For the configuration of the radio communications of the datalogger, see section 2.3 of this manual.

## 3.1.5. Data storage

The internal node memory size is 4 MB. The 5-channel datalogger connected to 5 sensors stores up to 73.500 readings. The 1-channel datalogger stores up to 200.000 readings. Times of data storage for LS datalogger 1 ch and LS datalogger 5 ch are indicated in Table 3. Memory mode is a circular buffer. When memory is full, logging continues by overwriting earliest readings. Besides the data from the sensor, health data is collected hourly, which indicates the battery voltage, the internal temperature of the node and the node uptime.

# Table 3: Times of data storage (without overwriting) for LS VW-datalogger 1 ch andLS VW- datalogger 5 ch.

Number of sensors	Sampling rate				
	60 minutes	30 minutes	10 minutes		
1	more than 10 years	more than 20 years	3.5 years		
5	8 years	4 years	17 months		

# 3.2. LS-G6-DIG

## 3.2.1. Sensor Connection

LS-G6-DIG datalogger supports 3 different sensor models by default (RS485 port):

- Geosense Inclinometer (<u>http://www.geosense.co.uk/products/details/mems-inclinometer-vertical-in-place</u>)
- RST inclinometer (<u>http://www.rstinstruments.com/ln-place%20Vertical%20MEMS%20Inclinometer.html</u>)
- Sisgeo inclinometer (<u>http://www.sisgeo.com/products/inclinometers-and-tiltmeters/item/digital-mems-inclinometer-system.html</u>)
- More models can be added with the development of drivers by Worldsensing developers. Contact Worldsensing technical support.

Regarding power consumption Worldsensing ensures that up to 30 Geosense / RST inclinometers can be safely powered from the datalogger. For the Sisgeo inclinometer 15

can be powered<sup>2</sup>. However up to 60 sensors may be read and transmitted by the datalogger. If more sensors are to be supplied, an external 12 V battery should be connected. In this case, contact Worldsensing.

The wiring is indicated in the RS485 port of the datalogger. The datalogger has to be placed at HALF to read the inclinometers. For the connection of digital dataloggers at SDI ports the wiring has to be checked at the sensor specifications.



Figure 47: View of the inside of the digital datalogger connected to a RST inclinometer and b) Sisgeo inclinometer.

LS-G6-DIG dataloggers (Figure 47) can also support other digital sensors, with SDI interface connection. These types of sensors are not supported by default by the datalogger, but drivers can be developed by Worldsensing engineers. The wiring for the sensors with SDI interfaces will depend on the model of the sensor; however, the label of each terminal is indicated.

b)

a)

<sup>&</sup>lt;sup>2</sup>Tested with a chain of 8 Sisgeo inclinometers.

#### 3.2.2. Battery lifespan

The following table gives the indicative battery lifespan per channel (Table 4 and Table 5). The user should take into account that consumption varies depending on the sensor used, the sampling rate and the environmental conditions.

#### 3.2.2.1. Geosense / RST IPI

Table 4: Indicative lifespan for LS-DIG datalogger. Estimations using 4 c-size cells

Number of sensors	Number	Sampling r	ate		
	of sensors	6 hours	2 hours	30 minutes	5 minutes
	10 (RS485)	>10 years	5.5 years	2.5 years	4 months
	30 (RS485)	5,2 years	10 months	4 months	26 days

#### 3.2.2.2. Sisgeo IPI



Number of sensors	Sampling rate					
	6 hours	2 hours	30 minutes	5 minutes		
8 (RS485)	4 years	13 months	6 months	35 days		

#### 3.2.3. Configuration

The configuration of the digital datalogger requires specifying the protocol of communication (from given options) and the bus addresses of the sensors connected in the RS485 port. This action is done through the Android Configuration App. The bus addresses of the digital sensors are specified by the manufacturers. Up to 30 sensors can be connected in a bus chain. When connecting the sensors, we recommend using resistors. In some cases, is clearly specified by manufacturer of the sensors.

For the configuration of the radio communications of the datalogger, see section 2.3 of this manual.

#### 3.2.4. Data storage

Capacity for up to 90.000 readings from the inclinometers, which are two-axis inclinometers with temperature variation calibration, grouped by 5 sensors. (Table 6).

 Table 6: Indicative storage capacity of the LS-DIG datalogger. Estimations using 5 sensors.

Number of sensors	Sampling rate				
	60 minutes	30 minutes	10 minutes		
5	more than 10 years	5 years	20 months		

# 3.3. LS-G6-ANALOG

#### 3.3.1. Sensor Connection

LS-G6-ANALOG datalogger supports 6 different sensor models that can be connected independently to four different channels (Figure 48):

- Voltage (+/- 10 V peak to peak)
- Full Wheatstone Bridge (39.06 mV)
- Thermistor (-40 to 85 °C for a standard 3K ohms)
- Current Loop (4-20 mA, 2 or 3 wires)
- Potentiometer (5 V)
- PT100 (-40 to 85°C)



Figure 48: View of the LS-G6-ANALOG datalogger internally where the four channels can be identified.

The wiring of the sensors is indicated in the Android configuration app, once the type of sensor to be connected to the channel is selected (Figure 49).





Figure 49: View of the wiring of the different types of analogue sensors, indicated in the Android Configuration App.

The datalogger can measure both voltage differential and single ended voltage sensors outputs. The standard wiring is for differential, and for single ended it is necessary to wire the negative input of the datalogger to the datalogger ground.

The wiring can be connected once the Setup Wizard in the Android Configuration App has been initialized, which is when the wiring schemes appear.

## 3.3.2. Battery lifespan

The following tables give the indicative battery lifespan for the LS-ANALOG datalogger, (Table 7 a, b and c) depending on the type of sensor, the warm up time and the sampling rate. The user should take into account that consumption varies depending on the sensor used, the sampling rate and the environmental conditions.

 Table 7: Indicative lifespan for LS-ANALOG datalogger. Estimations using 4 c-size cells, considering SF9

	Sensor features						
Channels & sampling	Current @12V@24mA	Current @12V@24mA	Current @24V@24mA	Current @24V@24mA			
Warm up time	1 second	5 seconds	1 second	5 seconds			
1 CH 5 min	6 months	3 months	4 months	2 months			
1 CH 30 min	2.5 years	1 year	2 years	1 year			
1 CH 1 hour	5.5 years	2.5 years	3.5 years	1.5 years			
1 CH 6 hours	>10 years	>10 years	>10 years	9.5 years			
4 CH 5 min	1.5 months	39 days	39 days	1 month			
4 CH 30 min	9 months	7.5 months	7.5 months	6.5 months			
4 CH 1 hour	1.5 years	1 year	15 months	1 year			
4 CH 6 hours	8 years	6.5 years	6.5 years	5.5 years			

a)

b)

Channels & sampling Sensor features

	Voltage @12V@24mA	Voltage @12V@24mA	Voltage @24V@24mA	Voltage @24V@24mA
Warm up time	1 second	5 seconds	1 second	5 seconds
1 CH 5 min	5 months	2.5 months	1.5 years	2.5 months
1 CH 30 min	2.5 years	1 year	10 months	1.5 years
1 CH 1 hour	4.5 years	2.5 years	1.5 years	2.5 years
1 CH 6 hours	>10 years	>10 years	8.5 years	>10 years
4 CH 5 min	2 months	1 month	1.5 months	25 days
4 CH 30 min	1 year	6 months	10 months	5 months
4 CH 1 hour	2 years	1 year	1.5 years	10 months
4 CH 6 hours	>10 years	5 years	8.5 years	4.5 years

#### c)

	<b>0 1 1</b>					
Channels	Sensor featu	res				
& sampling	FWB@5V@ 0.7 kΩ	FWB@5V @1.4 kΩ	Potentiomet er@5V@1.5 kΩ	Potentiometer@ 5V@5 kΩ	Thermistor@5V @3 kΩ	PT100
1 CH 5 min	1.5 years	1.5 years	1.5 years	1.5 years	1.5 years	1 year
1 CH 30 min	8 years	8 years	>10 years	8.5 years	8.5 years	5.5 years
1 CH 1 hour	>10 years	>10 years	>10 years	>10 years	>10 years	>10 years
1 CH 6 hours	>10 years	>10 years	>10 years	>10 years	>10 years	>10 years
4 CH 5 min	5 months	6 months	6.5 months	7 months	7.5 months	4 months
4 CH 30 min	2.5 years	2.5 years	3 years	3.5 years	3.5 years	1.5 years
4 CH 1 hour	4.5 years	5.5 years	5.5 years	6 years	6.5 years	3.5 years
4 CH 6 hours	>10 years	>10 years	>10 years	>10 years	>10 years	>10 years

#### 3.3.3. Configuration

The configuration requires specifying the excitation power voltage and the warm-up time for the sensors that need power supply (voltage and current loop sensors). For the other sensors, 5V excitation supply is present in all channels connectors.

Excitation power voltage can be 12 V or 24 V, and warm-up times: 100, 300 and 500 milliseconds or 1, 2, 5 and 10 seconds.

See section 2.3 for the configuration of the radio communications of the datalogger.

## 3.3.4. Data storage

#### Capacity for up to 130.000 readings with 4 sensors connected (

Table 8).

Table 8: Indicative storage capacity of the LS-ANALOG datalogger. Estimations usin	g
4 sensors.	

Number of	Sampling rate				
sensors	60 minutes	30 minutes	10 minutes		
4	more than 10 years	7 years	2.4 years		

# 4. WIRELESS RADIO

# 4.1. Maximum number of dataloggers connected in a network

The number of dataloggers that can be connected in a radio network is limited by the number of messages that can be transmitted over a period of time. All nodes in the network take their readings at a synchronized time (e.g. if reading every 5 minutes, it's every hour, at minute 0,5,10,15 and so on.). These messages are then written to internal node memory, but are not transmitted immediately. The readings are transmitted to the gateway at a random time inside a communication slot (Figure 50).





The length of the communication slot depends on the number of nodes in a network (Table 9), and is chosen automatically by the Android Configuration App when a node gets configured. There are also combinations of network size and sampling rate which are not supported. This is to prevent all nodes from sending at the same time and saturating the network.

	0-20	20-100	100-200	200-1000	1000-2000
10 secs	NO	NO	NO	NO	NO
30 secs	20	NO	NO	NO	NO
1 min	40	NO	NO	NO	NO
5 mins	60	240	NO	NO	NO
15 mine	60	600	600	NO	NO

Table 9: Slot times table. Columns are the number of nodes; rows are sampling rate.Slot times are in seconds.

30 mins	60	600	900	NO	NO
1h	60	600	900	2700	NO
6hrs	60	600	900	2700	3600
12hrs	60	600	900	2700	3600
24hrs	60	600	900	2700	3600

Note that LS-DIG doesn't necessarily comply with the slot times table (Table 9) because reading may take longer than VW or ANALOG dataloggers.

## 4.2. Radio configuration

Region and country: These values have to match the location where the dataloggers are deployed, in order to comply with the local regulations. There is a specific gateway model for each region, and the gateway must also be configured to the correct country / radio mode (Table10). In order to achieve communication, the gateway and all the dataloggers on a network need to be configured in the same way.

- 923A-legacy radio: This radio mode has some differences to the radios on other modes. In the rest of the countries, the gateway is always listening to all Spreading Factors, and on different frequencies. The datalogger can choose which SF and frequency to transmit on. In this mode, this is not possible. The gateway and all dataloggers must be configured to a Specific Spreading Factor and channel, which must be the same for all devices on the network. The default values are Channel 1, Spreading Factor 9, so these will be the values used if the Advanced options were ignored on both the gateway and the Dataloggers.
- Network ID and password:
  - These values are used to identify a radio network, and to protect (encrypt) the data in transit. A strong password will prevent a malicious attacker from both reading data from your sensors and from inserting bogus data posing as a sensor.
  - The radio network ID is set by default to the gateway's serial number, but it can be changed. For example, if you are replacing a gateway, you might want to set the new gateway (with a new serial number) to the old gateway's network ID, so that the dataloggers don't have to be reconfigured.
  - The network password is set by default to a randomly generated value, which is printed on your Gateway Information sheet. The generated password is unique to each gateway unit, so it can be used safely.
  - In order to achieve communication, the gateway and all the dataloggers on a network need to be configured with the same network ID and password.
  - For security reasons, the network password cannot be read from a datalogger by the Dlog Android app. For this reason, when entering the radio configuration dialog, the password displayed is the last one that was set using this Android device.
- Advanced options:
  - (Europe only) ETSI limit duty cycle: The European Telecommunications Standards Institute (ETSI) defines a time limit during which a radio device

may transmit on a given frequency over a 1-hour period. In some rare cases (high sampling rates on high SF), the datalogger may exhaust its radio time, and it will stop transmitting until the next hour. This option can be disabled for testing purposes, or for use in places where the norm doesn't apply (e.g. Inside a mine)

- Maximum Spreading Factor: Defines the maximum spreading factor the datalogger is allowed to transmit to.
  - Lower spreading factors allow for faster data transmission, so more dataloggers can share the same radio space.
  - Higher spreading factors allow for more reliable data transmission, allowing for longer distances and better immunity to interference.
- ADR (All modes except 923A-legacy): ADR (Adaptive Data Rate) is the mechanism which allows the datalogger to automatically negotiate the lowest viable spreading factor with the gateway. When the ADR is off, the datalogger will always use the highest SF (as set on the previous selector).
- Transmit power: Allows adjusting of the transmit power, in dB. The maximum allowed transmit power is specific to each country.
- Channel (923A-legacy only): It's possible to choose between 4 different channels in Australia:
  - o Channel 1: 921.9 MHz
  - o Channel 2: 922.5 MHz
  - o Channel 3: 923.7 MHz
  - o Channel 4: 924.3 MHz
- Channel group (FCC only): In FCC mode, the radio will use frequency hopping on a group of 8 channels. You may want to use a different channel group in order to move away from interferences on specific channels. All devices on a network (the gateway and all dataloggers) must be set to the same configuration. There are 8 groups to choose from:
  - o Group 0 (Channels 00-07) 902.3 to 903.7 MHz
  - Group 1 (Channels 08-15) 903.9 to 905.3 MHz
  - o Group 2 (Channels 16-23) 905.5 to 906.9 MHz
  - o Group 3 (Channels 24-31) 907.1 to 908.5 MHz
  - o Group 4 (Channels 32-39) 908.7 to 910.1 MHz
  - o Group 5 (Channels 40-47) 910.3 to 911.7 MHz
  - Group 6 (Channels 48-55) 911.9 to 913.3 MHz
  - o Group 7 (Channels 56-63) 913.5 to 914.9 MHz

#### Table 10: Summary of radio specifications by mode.

		EU	Malaysia	FCC	923P	923A	Australia 500 KHz	Singapore
	# of channels used by the gateway	8	8	8 (one group of 8 available)	8	8	1 (4 available)	6
oad	Channel's frequencies (MHz)	868.1, 868.3, 868.5, 868.85, 869.05, 869.525	869.1, 869.3, 869.5, 869.7, 869.9	Group 0: 902.3, 902.5, 902.7, 902.9, 903.1, 903.3, 903.5, 903.7 Group 1: 903.9, 904.1, 904.3, 904.5, 904.7, 904.9, 905.1, 905.3 Group 2: 905.5, 905.7, 905.9, 906.1, 906.3, 906.5, 906.7, 906.9 Group 3: 907.1, 907.3, 907.5, 907.7, 907.9, 908.1, 908.3, 908.5 Group 4: 908.7, 908.9, 909.1, 909.3, 909.5, 909.7, 909.9, 910.1 Group 5: 910.3, 910.5, 910.7, 910.9, 911.1, 911.3, 911.5, 911.7 Group 6: 911.9, 912.1, 912.3, 912.5, 912.7, 912.9, 913.1, 913.3 Group 7: 913.5, 913.7, 913.9, 914.1, 914.3, 914.5, 914.7, 914.9	921.4, 921.6, 921.8, 922, 922.2, 922.4, 922.6, 922.8	917.2, 917.4, 917.6, 917.8, 918, 918.2, 918.4, 918.6	921.9, 922.5, 923.7, 924.3	920.9, 921.2, 921.5, 922.8, 923.1, 923.4
Upl	Channel bandwidth (KHz)	125	125	125	125	125	500 (short range)	125
	# of channels used by the gateway	8	8	8 (one group)	8	8	1 (4 available)	6
wnload	Channel's frequencies	868.1, 868.3, 868.5, 868.85, 869.05, 869.525	869.1, 869.3, 869.5, 869.7, 869.9		921.4, 921.6, 921.8, 922, 922.2, 922.4, 922.6, 922.8	923.3, 923.9, 924.5, 925.1, 925.7, 926.3, 926.9, 927.5	921.9, 922.5, 923.7, 924.3	920.9, 921.2, 921.5, 922.8, 923.1, 923.4
õ	Channel bandwidth (KHz)	125	125	500	125	500	500	125
	Upload/Download same channels?	Yes	Yes	Yes	Yes	No	No	Yes
	Power transmission (by default) (dB)	14	14	20	20	20	20	20
	# of available Spreading Factors	5	5	5	5	5	5	5
	# of used Spreading Factors per network	5	3	3	5	1		
	Configuration in datalogger	-	-	Channel group (Group 0 by default)	-	-	Channel and SF	-
	Configuration in gateway	-	-	Channel group (Group 0 by default)	-	-	Channel and SF	-

# 4.3. Results of signal coverage test

In section 2.3, the signal coverage tests are presented. There are several ways do get the results of the signal coverage tests:

- Receiving the results of the signal coverage tests in the Android Configuration App (Figure 12).
- 2) They are also displayed geographically in the software of the gateway (Figure 51). In this case, your computer has to be connected to the Internet, to get the map. The position where the tests have been carried out is displayed with a specific symbol that related to the coverage at the specific point. The symbol selected (color legend) indicates the maximum SF from which >50% of the information packages sent by the datalogger have reached the gateway. In red, the places where ≤50% of the packages of SF 12 are indicated. The gateway is also indicated in the map.
- 3) Moreover, the results of the signal coverage tests can be downloaded from the gateway in a .csv file (Figure 51, lower right corner). If the test is done "offline", the results only appear in this .csv.

Note that whether or not the gateway has received the data from the tests, all the tests are saved in a .csv file inside the Android device (DLOG directory). Geographical data is also saved there (if GPS is activated in the Android).



Figure 51: View of the geographical display (in the software of the gateway) indicating the results of the signal coverage tests.

# 5. CONTACT WORLDSENSING

*Phone*: +34 93 418 05 85 (08.30h - 16.30h UTC)

Technical support: <a href="mailto:industrialsupport@worldsensing.com">industrialsupport@worldsensing.com</a>

General information: <a href="mailto:info@worldsensing.com">info@worldsensing.com</a>

Worldsensing SL

Aragó 383, 4<sup>th</sup>

08013 Barcelona

Spain

# Annex 1: Details of mounting systems

# Mounting brackets

#### Metallic versions



Polycarbonate version



# Strong magnets



# Pole mounting







# Annex 2: Android compatibility

The Android Configuration app specifically developed to connect locally with the LS-G6 (LS-G6) dataloggers, allowing configuration, data display and download. This document provides the basic information to know which Android devices are compatible with the LS-G6 dataloggers, and the USB cable that must be used for this local connection.

To download the Android Configuration App in your Android device, go the following link: <u>http://wsop.cat/industrial/dlog/Dlog.apk</u>. Information on how to use the application can be found in the LS-G6 user guide.

In order to be compatible with the LS-G6 dataloggers, an Android device must have the following specifications: USB on the go (OTG) + Android at least 3.1. From early 2013 most of the Android devices on the market fulfil these requirements. To check if your Android device includes the USB OTG feature, just search in the web "<model of the smartphone> specifications USB OTG" and ensure that the Android version is at least 3.1 (API version 12). Alternatively, you can download the following app, called USB OTG CHECKER: <a href="http://www.pcnexus.net/2014/07/how-to-check-android-phone-tablet-for-usb-otq-support.html">http://www.pcnexus.net/2014/07/how-to-check-android-phone-tablet-for-usb-otq-support.html</a>.

Some Android devices may have the USB OTG feature locked. An example of unlocking process for Samsung SIII mini can be found in this tutorial: <u>https://www.youtube.com/watch?v=JevEyriLXZ0.</u>

The connection between the LS-G6 datalogger and the Android device is done with "USB on the go" cable (OTG). This cable allows an Android device to act as "master", meaning that other devices can be controlled from it. The LS-G6 dataloggers have a mini USB connection, while most Android devices have a micro USB connection. In order to connect the Android device to the datalogger an USB OTG cable from micro USB to mini USB is needed.



# Annex 3: LS-G6 water tightness

The LS-G6 family of dataloggers from Worldsensing Industrial (WSI) are rated IP67. The dataloggers also pass the IP68 tests for extended immersion (1 meter for 3 days) if the installer uses extreme caution.

To ensure this condition, the user should be sure that:

 After sensor connection, the box is closed following a cross-shape order. By not following this order, the parallelism between base faces and cover may be missed, screwing may become more difficult and it can eventually generate a deformation of the screw threats or the helicoil inserts. Moreover, the toric joint (seal) would not seal properly, so the degree of protection against water intrusion (IP) would not be guaranteed.



- The box is screwed at 2 Nm, using a torque screwdriver (e.g. Ref. 1227107 from WERA)
- The cable glands are closed using a 19 mm open spanner (e.g. Bahco 19 mm Single Ended Open Spanner; RS Amidata code 717-8992) (holding the internal nut using a 22 mm open spanner (e.g. Bahco 22 mm Single Ended Open Spanner; RS Amidata code 717-8995).
- The antenna is mounted. If it is not, the antenna connector should be covered with a cap.
- The sealing ring is not manipulated, neither physically or chemically.

If any of these conditions are not given, or if one or several components (e.g. gore valve) are damaged, the IP67 and superior are not guaranteed.

In the case that it is necessary that the datalogger is further sealed, due to being placed in an extreme environment or in a floodable manhole, additional sealants would be required to close the box (e.g. Sikaflex products).

Note that box screws shouldn't be torqued more than 2.5 Nm, for all that the maximum torque that can be supported by the box screws is 3.5 Nm. If the torque is exceeded, the helicoil insert may be damaged. It is not recommended to use electric drills or electric screwdrivers.

# Annex 4: Recommended batteries

LS-G6 can work with only one cell battery or more than one (up to four). The more batteries used, the longer the autonomy is.

The recommended batteries are LSH 14 models from Saft.



This equipment can work with just one cell of a battery specified in the following link. (<u>http://www.saftbatteries.com/force\_download/LSH\_14.pdf</u>). More paralleled batteries increase the node autonomy

If another model of battery is used, it must meet the same specifications as the Saft batteries. Typical issues will be:

- Cell voltage: must be at least 2.7V to 5V
- Cell continuous current: Must he high current from 500 mA to 1 A

Cell voltage and continuous current change with temperature. Previous specs must be checked in the desired temperature range. Also common batteries (alkaline) don't work in extreme temperatures.

WARNING: THERE IS RISK OF EXPLOSION IF THE BATTERIES ARE SUBSTITUTED FOR AN INCORRECT MODEL. DISPOSE OF BATTERIES ACCORDING TO THE INSTRUCTIONS. THIS EQUIPMENT IS MEANT TO BE INSTALLED IN RESTRICTED ACCESS AREAS.

# Annex 5: Communications security

# Long range radio communication from dataloggers to gateway

This section explains the security of the radio communication from dataloggers to gateway.



#### Security

Each LS radio network uses its own identifier and password. The ID and password provide authentication and encryption to all radio communications within the network. This means that the ID and password are set on both the gateway and the dataloggers (via the USB Dlog Android app). By default, the gateway comes with a randomized password.

## Encryption

The radio network has a special need for secure communication, as many of its applications imply critical data of key infrastructures. This has been solved applying three encryption layers:

- Unique Network key (EUI64) at network level.
- Unique Application key (EUI64) at application level.
- Network specific key to encrypt all data using <u>AES</u>-128 (AES-EUI128).

## Gateway user access

This section explains how communication between the user and the gateway is secured.

#### Remote access

This is the method used to access the gateway over the internet or a local network. The gateway has two interfaces integrated for remote access:

- Ethernet interface
- 3G/GPRS interface

Both interfaces use HTTPS protocol for secure communication, and both interfaces use the remote access password. This password is unique and is randomly generated at production: it can be changed by the user using the gateway administration web. The different methods for remote access to the gateway (for more information please refer to the LS-G6 user guide) are shown here:



#### Local administration

The gateway offers the possibility of direct local connection, using gateway's internal USB port (for more information please refer to the LS-G6 user guide). When accessed by this method, the connection is also secured using https. However, this connection will ask for a password which is not unique (it is the same for all gateways). This is done taking two important considerations into account:

- A direct data recovery method is needed if the remote access password is lost.
- The gateway cannot be physically reached by anyone other than the customer.



Note: If your gateway is located where it might be physically accessed by unauthorized users, please contact Worldsensing technical support.

Data protection and communications security is highly emphasized in Worldsensing's products:

- The radio communication from the dataloggers to the gateway is encrypted with AES.
- All remote communications that allow user's access to the gateways are done with https protocols.

Both security methods conform to approved standards that are applied in all industries, from bank transactions through to most accessed internet services.

# Annex 6: Connecting an external modem to LS-G6

In this guide we'll be using an AirLink® RV50 from Sierra, but another similar device will work.

#### Initial configuration of AirLink RV50 (via Ethernet cable)

- Insert the SIM card following the device instructions. In our case, the Sierra AirLink RV50 has a cover with two Philips screws that gives access to the SIM Slots. The upper slot is the primary and is where SIM must be inserted. Optional: If you have a secondary SIM for fallback internet access, insert it on the lower slot.
- 2. Connect Cellular antenna.
- 3. Connect an Ethernet cable to your computer.
- 4. Connect power cable.
- 5. The device will give an IP address to your computer automatically. If not, or if you want to make sure that network settings are correct, follow the appendix on the last page.
- 6. Point your web browser to <a href="http://192.168.13.31:9191">http://192.168.13.31:9191</a> (AirLink RV50 factory IP)
- 7. Leave the administrator user name entered by default and enter the **default password: 12345** and click Login.
- 8. Optional: Change password. Go to Admin tab  $\rightarrow$  Change Password  $\rightarrow$  Enter Old password (12345) and then enter the new one.
- Main status page will appear with basic status information. Check the Network State field. If it is in Network Ready state and the Active WAN IP Address is different from 0.0.0.0, then your Sierra AirLink has auto-configured from your provider and you can skip to next chapter. If not, follow next steps to configure it.

Status	WAN/Cellular	LAN	VPN	Security	Services	GPS	Events Reporting	Serial	Applications	I/O	Admin		
Last updated time : 31/7/2016 17:15:53									Apply	Refresh	Cancel		
Home	Home			AT Phone Number					NA				
WAN/Cellular			AT Active WAN IP Address					0.0.0.0					
			AT Network State					SIM PIN incorrect 3 attempts left					
LAN	LAN			AT Cell Info					CellInfo: RSSI: -125				
VPN	VPN			Network Service Type					None				
			AT Signal Strength (RSSI)					-125					
Security			AT Channel					0					
Service	Services			WAN/Cellular Bytes Sent					0				
CDS	CDS		WAN/Cellular Bytes Rcvd					0					
642			Persisted WAN/Cellular Bytes Sent					0					
Serial	Serial			Persisted WAN/Cellular Bytes Rcvd					0				
Applica	tions		ALEOS Software Version					4.5.2					
			AT Customer Device Name					LT60940241	.011025				
About	About			Network Operator Switching					Disabled : SIM card not ready at boot				

#### 10. Go to WAN/Cellular tab $\rightarrow$ SIM Slot 1 Configuration.

Enter your network provider APN in **User Entered APN** field. If your SIM needs security PIN, set it via SIM PIN red button. A pop-up will appear:
Status	WAN/Cellular	LAN	VPN	Security	Services	GPS	Events Reporting	Serial	Applications	1/0	Admin	
ast updat	ted time : 31/7/2016 :	17:16:12							Expand All	Apply	Retresh	Can
WAN/Ce	ellular		L1Netwo	rk Credentials								
SIM Slot	t 1 Configuration		APN in	Use				APN Not Fou	ind			
SIM Slot	t 2 Configuration		AT User I	Entered APN								
Reliable Static Route (RSR)			IN				SIM PIN					
DMNR Configuration			[-] Advan	ced								
			AT LTE Authentication Mode					NONE   0				
			AT Network User ID									
			AT Network Password									
			[-] APN Backup									
			APN									
			LTE Au	thentication Mo	de		(	NONE 0				
			Networ	k User ID								
			Networ	k Password								

Then Save & reboot the device (Upper left Reboot button).

SIM PIN	<u>Close</u>
SIM Pin:	<ul> <li>Don't change</li> <li>Enable</li> <li>Disable</li> </ul>
Enter SIM Pin:	****
Retype SIM Pin:	••••
	Save Cancel
Status:	SIM PIN incorrect 3 attempts left

11. After rebooting device, access its configuration web again

(http://192.168.13.31:9191) and then check Network Sate, if everything works as expected it would be "Network Ready", and an Active Wan IP Address should be present.

Status	WAN/Cellular	LAN	VPN	Security	Services	GPS	Events Reporting	Serial	Applications	I/O	Admin		
Last updat	ted time : 31/7/2016	17:33:06								Apply	Refresh Cancel		
Home			AT Phone	Number				NA					
WANICe	llular		AT Active	WAN IP Addres	ss			10.40.246.14	11				
TIMITOC			AT Networ	k State				Network Rei	ady				
LAN AT Cell Info							CellInfo: TCI	4: 10688 RSSI: -10	2 LAC: 2114	4 CellID: 31868			
VPN AT Current Network Operator							214-19						
			AT Radio Technology						UMTS, Roaming				
Security			Network Service Type					3G					
Services			AT Signal Strength (RSSI)					-102					
			AT Signal Quality (ECIO)					-7.0					
GPS			Received Signal Code Power (RSCP)					-109.0					
Serial			AT Chann	el				10688					
	81		WAN/C	Cellular Bytes S	ent			3682					
Applica	tions		WAN/C	Cellular Bytes R	cvd			6900					
About			Persist	ed WAN/Cellul	ar Bytes Sent			3352					
			Persist	ed WAN/Cellul	ar Bytes Rovd			6760					
			ALEOS	Software Vers	ion			4.5.2					
			AT Custor	ner Device Nar	ne			LT60940241	011025				
			Netwo	k Operator Sw	itching			ок					

Led indicators will help diagnosing problems. If the gateway has internet connection, the first led (right-to-left) will be bright amber. The second led will be green if it has network signal too. The third led will indicate local network traffic.

If those first LEDS are blinking red, it means that the gateway still doesn't have signal or internet, or this needs to be reconfigured.



12. Finally, if the first two LEDS are fixed amber and green, check that your computer has internet access via AirLink RV50 (Open a web page, etc.). If not, repeat from step 9 and double check device settings.

If your computer now has internet access provided by LTE/3G, then we can jump to the final step.

#### Final Step: Connecting the LS-G6 Gateway to AirLink RV50

In order to connect the LS-G6 Gateway to the Internet via your recently configured AirLink RV50, this scheme must be followed. Please double check connections before powering on POE adapter or devices may be damaged.



After connections are made and devices powered on, LS-G6 will reach the Internet through your AirLink RV50 and should be accessible via its Remote Access URL. Please check the LS-G6 gateway information sheet for more information.

## Annex 7: Connecting a Wi-Fi module to LS-G6

In this guide we'll be using a NanoStation loco M2 from Ubiquity, however another Wireless bridge (commonly named "Access Point") can be used if it supports Client mode (also known as Station Mode).

We will follow those steps:

• First configuration of Wireless Bridge (via Ethernet cable). We recommend doing this step within the Wireless Network range, but without installing the device on its final location. You'll need a computer and be able to temporarily change its IP address.

• Wireless Bridge physical installation. Now you can install the device (using its cable tie) to the final location, pointing to the source of Wireless Network.

• **Review LS-G6 Gateway (via Ethernet cable).** In this step you will assure that LS-G6 Gateway is expecting configuration via Ethernet and is able to connect directly to internet.

• Interconnection between Wireless Bridge and Loadsensing Gateway

1. Connect an Ethernet cable from the NanoStation to the POE port of the PoE Adapter. Please make doubly sure that you connect the POE port to the antenna and NOT to your computer as it could be damaged.

2. Connect another Ethernet cable from your computer to the LAN port of the PoE Adapter.

3. Your computer now needs a temporary IP address within the 192.168.1.x subnet. For example, assign 192.168.1.100 address and 255.255.255.0 netmask. Leave gateway and DNS blank. Depending on your Operating System the procedure might be different. If your computer is a laptop make sure you change the IP address for the LAN (cabled) adapter and not wireless one. Tip: Check Appendix on last page for more information

4. Direct your web browser to http://192.168.1.20 (This is the NanoStation factory IP address)

5. Accept unsigned certificate warnings

6. Enter ubnt as both User Name and Password

7. The airOS configuration interface will appear. For security reasons, the first thing you should do is configure a new password to access the device. We recommend doing it now because the device will force you to change it later while configuring the Wireless Network

8. Go to System tab  $\rightarrow$ System Accounts. Click on the key symbol to change the ubnt password. Note: For added security, we recommend changing both the username and password

9. The next step is to search for the Wireless Network and connect to it. Go to Wireless tab and make sure that Wireless Mode is set to Station. Then go to Select Button to do a Wireless Networks Survey:

Wireless Mode:	Station	٥	
WDS (Transparent Bridge Mode):	Enable		
SSID:	ubnt		Select
Lock to AP:			
Country Code:	Spain	0	
IEEE 802.11 Mode:	B/G/N mixed	\$	
Channel Width:[?]	Auto 20/40 MHz	\$	
Frequency Scan List, MHz:	Enable		
Calculate EIRP Limit:	Enable		
Antenna:	Built in (2x2) - 8 dBi	0	
Output Power:		1	12 dBm
Data Rate Module:	Default	0	
Max TX Rate, Mbps:	MCS 15 - 130/144.4 [27(	٥ 6	Auto
/ireless Security			
Security:	none	0	

10.The Site Survey window will appear, listing all the Wireless Networks in your area. Then you choose your SSID (Network) and confirm it with the Select Button.

	MAC Address	SSID	Device Name	Radio Mode	Encryption	Signal / Noise, dBm	Frequency, GHz / Channel
	4C:5E:0C:71:5C:B8	Dharma	4C5E0C715CB8	802.11n	WPA2	-33 / -98	2.412/1
>	14:CC:20:50:E6:D4	Jazztel_08		802.11n	WPA	-64 / -98	2.412/1
)	E8:39:DF:FC:6B:35	Jazztel_08		802.11n	WPA2	-70/-98	2.412/1
)	B2:46:FC:67:2A:00	MOVISTAR_2A00		802.11n	WPA2	-90/-99	2.462/11

11.After selecting your preferred SSID (Network) the browser will return to the Wireless Settings tab.

There's one last and important thing to do: Set the Wireless Password or encryption Key! On the bottom of this page, Wireless Security will be auto-detected with selected network encryption setting. The password must be written on the textbox and saved with the Change button.

Tip: Tick "Show" to check if password is correct while you are writing.

		× 1			
WPA Authentication:	PSK   ¢				
WPA Preshared Key:			Show		

12. As with every change that is made in Ubiquity Devices, it must be Applied to take effect:

lanoStat	tion loco I	<b>M</b> 2						a	<b>°</b> 08
*	MAIN	WIRELESS	NETWORK	ADVANCED	SERVICES	SYSTEM	Tools:	-	Logout
Configura	ation contains cl	hanges. Apply th	ese changes?				Test	Apply D	iscard
Basic Wir	eless Setting	S							

13. After several seconds, the device will reboot and connect to Wireless Network. The last step is to remove the Default IP Address and let the device ask for IP to the Wireless Network. Go to Network Tab and change Management IP Address to DHCP.

Tip: Leave DHCP Fallback Address as 192.168.1.20. In this way, if something goes wrong and the device cannot get an IP address from Wireless Network, after several minutes it will get that «rescue IP» so you can connect to it with your laptop to reconfigure it.

After changing to DHCP mode, remember to Apply settings!

Now your Wireless Bridge will be connected to your Wireless Network as if it were a Laptop, a Mobile or another device. Then it will I convert this signal to Ethernet cable.

# Annex 8: Troubleshooting reference table

## Gateway

# Dataloggers

Fault	Possible cause	Remedy
Datalogger not visible to gateway	Datalogger isolated / not visible for anyone	Move location
Datalogger not visible to gateway. Cannot be accessed with Dlog unless switch is set to "USB".	Datalogger battery is dead	Check battery
Datalogger not visible to gateway	Radio configuration	Check radio configuration using DLOG. Check carefully that the radio configuration is the same on all devices.
Datalogger not visible to gateway	Antenna	Check connection & orientation
Datalogger not visible to gateway	Gateway	Check gateway is UP
Datalogger not visible to gateway	Gateway antenna	Check connection & orientation

## Annex 9: FAQ's

• The node appears as connected but the readings don't appear in the files.

When a node is out of time (1970) it appears as connected but the readings don't appear in the files, nor in "Last readings". A warning message appears in the "log" tab. You should reconnect to the node using the USB OTG cable and the DLOG app to set the date and time.

• I have done a few signal coverage tests but they don't appear on the map of the web interface.

Did you have GPS coverage? Were your android device and the gateway connected to internet? Latitude and longitude collected by the mobile in the signal coverage test is sent to the gateway through the internet so if your mobile or the gateway didn't have connectivity (offline test), latitude and longitude will be only stored in the mobile, in a csv file called 'signal-coverage', and not in the gateway.

• Is the datalogger protected over reverse polarity and over voltage?

Yes. The datalogger should not be damaged by a mis-wiring on the external cables, including input voltages of up to 20V

• Does the datalogger have ESD protection?

Yes. The datalogger should not be damaged by an Electrostatic discharge, in compliance with norm IEC 61000-4-2.

• Does the datalogger have surge protection?

As long as the datalogger has proper grounding, it should not be damaged by a short high voltage burst, such as a lightning strike at least 100m away.

Note that, while the dataloggers have been engineered and built to comply with these specifications, the surge protection has not yet been through certification, so we don't have an external test report to certify compliance on this aspect.

• How should the datalogger be installed?

The datalogger should be installed with proper grounding connected to the screw outside the box in order to guarantee surge immunity, especially on installations with long cable runs.

Is the gateway protected over surges?

The gateway does not ship with surge protection out of the box as the dataloggers do.

However, if this kind of protection is desired, it's possible to achieve it by using external devices.

The Antenna link should be fitted with a CITEL P8AX.

The Ethernet link should be fitted with a CITEL Mj8-POE-B.

Both devices must be installed according to their own specifications.

• What is the effect of strong winds (for example 80 km/h) on radio communications?

The impact of wind on radio waves is almost negligible.

• Is it possible to connect the gateway to the Internet (through 3G) as well as to a private network through Ethernet?

No, this is not possible. The gateway cannot have two active connectivity options at the same time. When it is using 3G, it will ignore the Ethernet and vice-versa. In the case that this would be a requirement, an external router may be used.

• Is it possible to connect a gateway to a Virtual Private Network (VPN)?

There are different protocols used to tunnel the traffic and also different VPN types so it is not simple to introduce VPN functions into the LS gateway software. If it is necessary to connect a gateway to a VPN, currently there are two options: use an external VPN router or contract a SIM card suitable for Private Networks from a telecommunications company.

• Is my data secure from unauthorized access?

The Loadsensing G6 server is hosted inside the gateway. The web page you see, where you download your CSVs from, is actually inside your own device, so your data never gets sent anywhere, unless you configure it otherwise (for example, using the ftp client feature).

Access to this information is protected by the Web Access password. We generate a random default password for each gateway (which is written in your Gateway Information Sheet), so no other customer has the same password.

If you want your web password to be changed from the default value, you can change it in the web interface.

When you access your information through https://loadsensing.wocs3.com/<gwid>, you are using the Loadsensing Remote Access Service. This service uses a Worldsensing server as a proxy to enable remote access to gateways with no public IP. The server however, is not a cloud storage service, does not store any of your information, and access still requires the web password.

• How do we deal with interferences?

As with any radio system, interference can cause difficulty in communication, leading to higher packet loss ratios. Most wireless systems (such as Wi-Fi) use the 2.4 GHz and 5 GHz bands. The sub-GHz bands are commonly less used by consumer devices, leading to less interference. The radio uses several systems to provide certain immunity to interference:

- o Co-channel Gaussian minimum shift keying
- Automatic minimum spreading factor selection

# Annex 10: Modbus memory maps

### **General Section**

Address	Register name	Register content	Accepted Values
40001	Global Map Version	Version of the global memory map. A change in this version means that all the memory map changes.	0

# **Common Section**

Address	Register name	Register content	Values
40051	Common Map Version	Version of the common section memory map. A change in this version means that there are changes in the common section but not necessarily in the other sections.	0
40052	Node ID High	ID of the LS-G6 node. High and Low bytes in consecutive registers.	0 to 35535
40053	Node ID Low		
40054	Node Product Code	Product Code of the LS-G6 Node	See product codes in LS - Command & Packets list V2.x document
40055	Health Received Timestamp High	Timestamp of the moment in which the last health message was received in the GW in seconds since the Unix epoch. GW time. High and Low bytes	0 to 4294967295
40056	Health Received Timestamp Low	in consecutive registers.	
40057	Health Node Timestamp High	Timestamp of the last health message in seconds since the Unix epoch. Node time. High and Low bytes in consecutive registers.	0 to 4294967295
40058	Health Node		

	Timestamp Low		
40059	Node Uptime High	Seconds from the last reboot of the node. High and Low bytes in consecutive registers.	0 to 4294967295
40060	Node Uptime Low		
40061	Node Battery Volts	Voltage of the battery in mV.	0 to 35535
40062	Node Temperature	Temperature in the node in °C	0 to 255
40063	Node Version Major	Node FW Version Major	0 to 255
40064	Node Version Minor	Node FW Version Minor	0 to 255

# Node Section

All the nodes have a common part in the Node section:

Address	Register name	Register content	Values
40101	Node Section Map ID	ID of the Node Section memory map. This defines the contents of the Node section from the register 30103 onwards.	0 - VW 1 - VLT 2 - DIG- GSI- Sisgeo
40102	Node Map Version	Version of the node section memory map. A change in this version means that there are changes in the node section but not necessarily in the other sections.	0 to 35535

LS-G6-VW

Address	Register name	Register content	Values
40101	Node Section Map ID	ID of the Node Section memory map. This defines the contents of the Node section from the register 30103 onwards.	0 - VW
40102	Node Map Version	Version of the node section memory map. A 0 change in this version means that there are changes in the node section but not necessarily in the other sections.	
40103	Data Received Timestamp High	Timestamp of the moment in which the last data message was received in the GW in seconds since the Unix epoch. GW time. High and Low bytes in consecutive registers.	0 to 4294967295
40104	Data Received Timestamp Low		
40105	Data Node Timestamp High	Timestamp of the last data message in seconds since the Unix epoch. Node time. High and Low bytes in consecutive registers.	0 to 4294967295
40106	Data Node Timestamp Low		
40107	Pressure	Pressure read by the node in hPa*10.	0 to 35535
40108	Channel 0 Presence	Shows if the channel 0 registers have valid data.	0: Channel not present 1: Channel present
			procent
40109	Channel 0 Frequency High	Frequency read on the VW in the Channel 0 in mHz. High and Low bytes in consecutive registers. 0 if the Channel Presence is 0.	0 to 7000000
40110	Channel 0 Frequency Low		
40111	Channel 0	Thermistor data read on the VW in the	0 to

	Thermistor High	Channel 0 in mOhm. High and Low bytes in consecutive registers. 0 if the Channel Presence is 0.	4294967295
40112	Channel 0 Thermistor Low		
40113	Channel 1 Presence	Shows if the channel 1 registers have valid data.	0: Channel not present
			1: Channel present
40114	Channel 1 Frequency High	Frequency read on the VW in the Channel 1 in mHz. High and Low bytes in consecutive registers. 0 if the Channel Presence is 0.	0 to 7000000
40115	Channel 1 Frequency Low		
40116	Channel 1 Thermistor High	Thermistor data read on the VW in the Channel 1 in mOhm. High and Low bytes in consecutive registers. 0 if the Channel Presence is 0.	0 to 4294967295
40117	Channel 1 Thermistor Low		
40118	Channel 2 Presence	Shows if the channel 2 registers have valid data.	0: Channel not present
			1: Channel present
40119	Channel 2 Frequency High	Frequency read on the VW in the Channel 2 in mHz. High and Low bytes in consecutive registers. 0 if the Channel Presence is 0.	0 to 7000000
40120	Channel 2 Frequency Low		
40121	Channel 2 Thermistor	Thermistor data read on the VW in the Channel 2 in mOhm. High and Low bytes in	0 to

	High	consecutive registers. 0 if the Channel Presence is 0.	4294967295
40122	Channel 2 Thermistor Low		
40123	Channel 3 Presence	Shows if the channel 3 registers have valid data.	0: Channel not present 1: Channel present
40124	Channel 3 Frequency High	Frequency read on the VW in the Channel 3 in mHz. High and Low bytes in consecutive registers. 0 if the Channel Presence is 0.	0 to 7000000
40125	Channel 3 Frequency Low		
40126	Channel 3 Thermistor High	Thermistor data read on the VW in the Channel 3 in mOhm. High and Low bytes in consecutive registers. 0 if the Channel Presence is 0.	0 to 4294967295
40127	Channel 3 Thermistor Low		

#### LS-G6-ANALOG

Address	Register name	Register content	Values
40101	Node Section Map ID	ID of the Node Section memory map. This defines the contents of the Node section from the register 30103 onwards.	1 - VLT
40102	Node Map Version	Version of the node section memory map. A change in this version means that there are changes in the node section but not necessarily in the other sections.	0
40103	Data Received	Timestamp of the moment in which the	0 to 4294967295

	Timestamp High	last data message was received in the GW in seconds since the Unix epoch. GW time. High and Low bytes in consecutive	
40104	Data Received Timestamp Low	registers.	
40105	Data Node Timestamp High	Timestamp of the last data message in seconds since the Unix epoch. Node time. High and Low bytes in consecutive registers.	0 to 4294967295
40106	Data Node Timestamp Low		
40107	Channel 0 Presence	Shows if the channel 0 registers have valid data.	0: Channel not present
			1: Channel present
40108	Channel 0 Input Type	Type of sensor connected to the channel 0.	See Input Type Codification Values table
40109	Channel 0 Data High	Data read on the node in the Channel 0. Units depend on the Input type. High and Low bytes in consecutive registers. 0 if	0 to 4294967295
40110	Channel 0 Data Low	the Channel Presence is 0.	
40111	Channel 1 Presence	Shows if the channel 1 registers have valid data.	0: Channel not present
			1: Channel present
40112	Channel 1 Input Type	Type of sensor connected to the channel 1.	See Input Type Codification Values table
40113	Channel 1 Data High	Data read on the node in the Channel 1. Units depend on the Input type. High and	0 to 4294967295

40114	Channel 1 Data Low	Low bytes in consecutive registers. 0 if the Channel Presence is 0.	
40115	Channel 2 Presence	Shows if the channel 2 registers have valid data.	0: Channel not present
			1: Channel present
40116	Channel 2 Input Type	Type of sensor connected to the channel 2.	See Input Type Codification Values table
40117	Channel 2 Data High	Data read on the node in the Channel 2. Units depend on the Input type. High and Low bytes in consecutive registers. 0 if	0 to 4294967295
40118	Channel 2 Data Low	the Channel Presence is 0.	
40119	Channel 3 Presence	Shows if the channel 3 registers have valid data.	0: Channel not present
			1: Channel present
40120	Channel 3 Input Type	Type of sensor connected to the channel 3.	See Input Type Codification Values table
40121	Channel 3 Data High	Data read on the node in the Channel 3. Units depend on the Input type. High and Low bytes in consecutive registers. 0 if	0 to 4294967295
40122	Channel 3 Data Low	the Channel Presence is 0.	

### LS-G6-DIG (Geosense/RST-Sisgeo)

Address	Register name	Register content	Values
40101	Node Section Map ID	ID of the Node Section memory map. This defines the contents of the Node section from the register 30103 onwards.	2 - DIG-GSI- Sisgeo

40102	Node Map Version	Version of the node section memory map. A change in this version means that there are changes in the node section but not necessarily in the other sections.	0
40103	Data Received Timestamp High	Timestamp of the moment in which the last data message was received in the GW in seconds since the Unix epoch. GW time. High and Low bytes in consecutive registers.	0 to 4294967295
40104	Data Received Timestamp Low		
40105	Data Node Timestamp High	Timestamp of the last data message in seconds since the Unix epoch. Node time. High and Low bytes in consecutive registers.	0 to 4294967295
40106	Data Node Timestamp Low		
40107	Number of Channels	Number of channels present in the data.	0 to 50
40108	Reserved		0
40109			0
40110	First register of t	he channels data. See below for more information	on.

A GSI node can have from 0 to 50 sensors connected. They are numbered from channel 0 to channel 49.

The following table has a description of the memory map for one channel. To calculate the address of the first register of a given channel, simply multiply the channel number (N) per 10 and add the base address 30110:

Channel N address = 30110 + (10 \* N)

Address	Register name	Register content	Values

40110 + (10 * N)	ChN Number Axis	Number of axis of the channel. Sensors can have one or two axis. If this value is 0 means that no data was received of this channel.	0, 1, 2
40110 + (10 * N) + 1	ChN Temperature	Temperature read on the Channel N. Codified in two's complement. Value in tenths of °C.	+/-1000 [°C*10] -32768 (0x8000): Invalid reading (sensor error) -32767 (0x8001): No data received from this channel (communication error)
40110 + (10 * N) + 2	Ch N Axis 1 Reading High	Inclination read from the Axis 1 sensor of the channel. Codified in two's complement. Value in % 10000.	+/-250000 [°*10000] -2147483648 (0x80000000): Invalid reading (sensor
40110 + (10 * N) + 3	Ch N Axis 1 Reading Low		error) -2147483647 (0x80000001): No data received from this channel (communication error)
40110 + (10 * N) + 4	Ch N Axis 2 Reading High	Inclination read from the Axis 1 sensor of the channel. Codified in two's complement. Value in % 10000.	+/-250000 [°*10000] -2147483648 (0x80000000): Invalid reading (sensor
40110 + (10 * N) + 5	Ch N Axis 2 Reading Low		-2147483647 (0x80000001): No data received from this channel (communication error)
40110 + (10 * N) + 6	Reserved		0
40110 + (10 * N) + 7			0

40110 + (10 * N) +	0
8	
40110 + (10 * N) +	0
9	