Minimate Pro6[™]

Series IV – Advanced Vibration, Overpressure and Sound Monitors

6 - Channel data acquisition for the following range of Applications:

- Blast-monitoring for compliance
- Multi-point monitoring
- Remote monitoring -Auto Call Home™
- Blast analysis
- Near and Farfield blast analyis
- Pile driving
- Construction activity
- Demolition activity
- Structural monitoring
- Underwater monitoring
- Heavy Transportation

The Instantel® Minimate Pro6TM vibration, overpressure and sound monitors are built on the success of the Minimate® Series III monitoring systems.

The **Minimate Pro6** offers 64MBs of memory, improved ruggedness, including a metal case and connectors, and water resistance.

Connect two standard ISEE or DIN Triaxial Geophones to monitor vibration sources from two different locations. Or, connect one ISEE or DIN Triaxial Geophone and an ISEE Linear Microphone or optional Sound Microphone when air overpressure or sound data is required.

Versatile

Each compliance sensors calibration date, serial number, and sample rate specification are determined by the Sensor Check feature of the unit and stored in the setup file. The sensor type, calibration date and serial number are also recorded on the Event Report.

For those challenging monitoring applications, such as tunneling, the **Series IV** units include EMI shielding and built-in noise and anti-aliasing filters; both the sensor and auxiliary channels are isolated.

With the optional **Instantel® Blastware® Advanced Module** perform VDV monitoring, Signature Hole Analysis, and real time display of Histogram data.

Intelligent

View Peak Vibration and Zero Crossing Frequencies immediately after each Event occurs. Toggle between Peak Vibration and Peak Overpressure with a simple push of a button. Data highlights including Operator, Trigger, Duration, and Maximum Vibration and Overpressure are also available for review, right on the monitors display.

Remote Monitoring

For remote installations, the **Instantel®** Auto Call HomeTM feature will automatically transfer event files from field to office as they are recorded using a variety of wireless modems. From there, the **Blastware** Mail feature of the **Instantel Blastware** software automatically distributes files or summary information to multiple e-mail addresses.





Instalink™

The **Auto Call Home** feature can also be used in conjunction with an optional service, **Instantel® InstaLinkTM**, leveraging the Internet to automate the process of transferring vibration data directly from an Instantel vibration monitor to a secure, password-protected web site for viewing by approved stakeholders.

Easy to use

Even with all of these features, the **Minimate Pro6** system is still easy for anyone to use. A high-contrast LCD and ten-key tactile keypad drives simple menu operations, while graphic icons indicate battery and memory levels at a glance.

Key Features

- Dedicated function keys and intuitive menu-driven operation enable quick and easy setup.
- Sample rates from 512 to 65,536 S/s per channel, independent of record times.
- Continuous monitoring means zero dead time between Events, even while the unit is processing.
- Instantel Histogram ComboTM mode allows capturing thousands of full waveform records while simultaneously recording in histogram mode.
- Auto Call Home feature automates remote monitoring applications.
- Non-volatile memory with standard 7,100-plus event storage capacity.
- Records full waveform events over two hours long.
- Match any channel with a variety of sensors; geophones, accelerometers, hydrophones and a microphone channel
- Optional Sound Microphone available for sound monitoring. Combine an ISEE or DIN Triaxial Geophone with the Sound Microphone to monitor two types of event data.

Minimate Pro6[™]

General Specifications

Minimate Pro6

Minimate Pro6 Channels

Vibration Monitoring

Range

Response Standard

Resolution Accuracy (ISEE / DIN)

Transducer Density

Frequency Range (ISEE / DIN)

Maximum Cable Length (ISEE / DIN)

Air Overpressure Monitoring

Weighting Scales Response Standard Linear Range

Linear Resolution Linear Accuracy

Linear Frequency Response

Cable Length

Optional Advanced Sensors

Contact Instantel for more information

Channels 1-3, ISEE (or DIN) Triaxial Geophone, and

Channels 4-6, a second ISEE (or DIN) Triaxial Geophone, or an ISEE Linear Microphone

Up to 254 mm/s (10 in/s)

ISEE Seismograph Specification or DIN 45669-1

0.00788 mm/s (0.00031 in/s)

+/- 5% or 0.5 mm/s (0.02 in/s), whichever is larger, between 4 and 125 Hz / DIN 45669-1 standard

2.13 g/cc (133 lbs/ft³)

2 to 250 Hz, within zero to -3 dB of an ideal flat response / 1 to 315 Hz or 1 to 80 Hz

75 m (250 ft) / 1,000 m (3,280 ft)

ISEE Linear Microphone

ISEE Seismograph Specification 88 to 148 dB (500 Pa [0.072 psi] Peak)

0.0156 pa (2.2662×10-6 psi)

+/- 10% or +/- 1 dB, whichever is larger, between 4 and 125 Hz

2 to 250 Hz between -3 dB roll off points

75 m (250 ft)

Sound Level Microphone, High Pressure Microphone, High Frequency Geophone, Uniaxial and Triaxial

Accelerometer, and Hydrophone

Record Modes Waveform, Waveform Manual Seismic Trigger 0.13 to 254 mm/s (0.005 to 10 in/s) Linear Acoustic Trigger 2.0 pa to 500 pa (100 dB to 148 dB)

Sample Rate 512, 1,024, 2,048, 4,096, 8,192, 16,384, 32,768, 65,536 S/s per channel (independent of record time)

Fixed record time, Instantel® AutoRecord™ record stop mode Record Stop Mode

1-9,000 seconds (1-30 seconds, then 30-second increments up to 150 minutes) plus a 0.25 seconds pre-trigger Record Time AutoRecord Time Event is recorded until activity remains below trigger level for duration of auto window, or until available

memory is filled.

2.27 kg (5 lbs)

10 Days

Recording uninterrupted by event processing, monitoring, or communication - no dead time below 65 KHz. Cycle Time

64 MBs. Optional 240 MBs.

Minimate Pro6 Storage Capacity Full Waveform Events 7,100-plus 1 second events at 1,024 S/s sample rate with two geophones

Histogram and Instantel Histogram Combo™ (monitor captures triggered waveforms while Record Modes

recording in Histogram mode) Recording Interval 1 to 30 seconds at 1 second intervals, and 30 seconds to 60 minutes at 30 second intervals

512,000 intervals, examples: 11.9 days at 2 second intervals, or 355 days at 1 minute Histogram Storage Capacity

Example: 30 days of Histogram recording at 1 minute intervals, and over 6,500 1 second waveform events Histogram Combo Storage Capacity

10 domed tactile with separate keys for common functions

7-line x 32-character, high-contrast, multi-color backlit LCD

Physical Specifications

Dimensions Unit Weight Battery User Interface Display PC Interface

Auxillary Inputs and Outputs Environmental

LCD Operating Temperature Electronics Operating Temperature

Remote Communications

Additional Features

Electrical Standards

-20 to 45 °C (-4 to 113 °F) -40 to 45 °C (-40 to 113 °F) Water Resistance

IP67 – submerse to 30 cm (1 ft.) for 24 hours Instantel approved serial communication modems

RS-232 with an optional USB adapter

External Trigger and Remote Alarm

Automatically transfers events when they occur through the Instantel Auto Call Home™ feature

Ethernet® cable, supplied, for PC to unit connection (Auto Call Home is not supported over Ethernet), or

Monitor start/ston timer

Optional InstaLink to leverage the Internet for automated processing of vibration data directly from an Instantel vibration monitor to a secure, password-protected web site, to be viewed by approved stakeholders.

25.4(l) x 11.75(w) x 10.80(h) cm (10.00 x 4.63 x 4.25 in); length dimension includes connectors and dust caps

CE Class B

Corporate Office: 309 Legget Drive, Ottawa, Ontario K2K 3A3 **US Office:** 808 Commerce Park Drive Ogdensburg, New York 13669 Toll Free: (800) 267 9111 Telephone: (613) 592 4642 Facsimile: (613) 592 4296

© 2013 Xmark Corporation. Instantel, the Instantel logo, Auto Call Home, AutoRecord, Blastmate, Blastware, Histogram Combo, InstaLink, and Minimate are trademarks of Stanley Black & Decker, Inc., or its affiliates.

720B0002 Rev 06 - Product Specifications are Subject to Change

